

From: [wayne price](#)
To: [Bratcher, Mike, EMNRD](#)
Subject: Delineation
Date: Monday, January 12, 2015 6:20:01 PM

Hi Mike,

Next week I am going to try and find the vertical extent at our BKE SWD and would like to know if the following parameters will work for you to determine when to stop.

The Groundwater depth is 60 ft, there are no waters wells within 200 ft, and no rivers etc.

Benzene 10 mg/kg 8021
BTEX 50 mg/kg 8021
TPH 1000 mg/kg 8015M
Chlorides 600 mg/kg 300.1

The area is surrounded by out of service farmland where it was irrigated with river-canal water that ranged from 500-2200 ppm Cl. Most of the surrounding area has heavy Sulfate and Salt stains from past farming.

Please let me know if this will work?

Wayne Price-PriceLLC