Submit 3 Copies To Appropriate District Office	State of New Mexico		Form C-103	
District I	Energy, Minerals and Natural F	esources WELL API NO.	June 19, 2008	
1625 N French Dr, Hobbs, NM 88240 District II	OIL CONSERVATION DIV	20.015	-39714	
1301 W Grand Ave, Artesia, NM 88210 District III	1220 South St. Francis	5. Indicate Type of Lo		
1000 Rio Brazos Rd, Aztec, NM 87410	Santa Fe, NM 87505	SIAIE 🔼	FEE	
<u>District IV</u> 1220 S. St. Francis Dr , Santa Fe, NM	Santa 1 0, 14141 07303	6. State Oil & Gas Le	ease No.	
87505 SLINDRY NOT	CES AND REPORTS ON WELLS	7. Lease Name or Un	it Agreement Name	
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO DEEPEN OR PLUG BA	CK TO A	it Agreement Name	
DIFFERENT RESERVOIR USE "APPLIC PROPOSALS)	CATION FOR PERMIT" (FORM C-101) FOR SU	CH Kiowa	a State	
1. Type of Well: Oil Well	Gas Well Other	8. Well Number		
2. Name of Operator		9. OGRID Number		
COG Operating LLC			229137	
3. Address of Operator			10. Pool name or Wildcat	
	ve., Suite 100 Midland, TX 79701	Red Lake; Glorieta-Yo	eso, Northeast 96836	
4. Well Location	March V	1 1440 C . C . J . W	1.	
		nd 1440 feet from the West		
Section 36 Township 17S Range 27E NMPM County Eddy 11. Elevation (Show whether DR, RKB, RT, GR, etc.)				
	3596' GR	, N1, ON, CIC.)	And the second	
Expression of the standard of				
12. Check A	Appropriate Box to Indicate Natur	e of Notice, Report or Other Da	ta	
NOTICE OF IN	TENTION TO:	SUBSEQUENT BEDO	DT OF.	
NOTICE OF IN PERFORM REMEDIAL WORK □		SUBSEQUENT REPOMEDIAL WORK	TERING CASING	
TEMPORARILY ABANDON			AND A	
PULL OR ALTER CASING	MULTIPLE COMPL CA	SING/CEMENT JOB		
DOWNHOLE COMMINGLE				
OTHER:	ОТ	HER: Completion		
	oleted operations. (Clearly state all pertin	ent details, and give pertinent dates, in		
13. Describe proposed or comp of starting any proposed we		ent details, and give pertinent dates, in		
13. Describe proposed or comp of starting any proposed we or recompletion.	oleted operations. (Clearly state all pertin	ent details, and give pertinent dates, in		
13. Describe proposed or compof starting any proposed we or recompletion. 2/21/12 Drill out DVT.	oleted operations. (Clearly state all pertin	ent details, and give pertinent dates, in		
13. Describe proposed or composed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to	oleted operations. (Clearly state all pertions). SEE RULE 1103. For Multiple Co	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram o		
13. Describe proposed or composed of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26	oleted operations. (Clearly state all pertions). SEE RULE 1103. For Multiple Co 3500 psi for 30 mins. Ok. nebry @ 4360 - 4610 w/ 1 SPF, 20 8 gals acid. Frac w/115,681 gals of	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. The holes is holes and the holes are the holes. The holes is hole to be a set of the holes and the holes are the holes are the holes.	of proposed completion , 31,332# 16/30	
13. Describe proposed or compof starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set	oleted operations. (Clearly state all pertions). SEE RULE 1103. For Multiple Co 3500 psi for 30 mins. Ok. nebry @ 4360 - 4610 w/ 1 SPF, 20 8 gals acid. Frac w/115,681 gals of CBP @ 4330. Perf Middle Blinebr	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. Hel, 145,378# 16/30 brady sand y @ 4050 - 4300 w/1 SPF, 26 h	of proposed completion , 31,332# 16/30 noles.	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24.	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Co 3500 psi for 30 mins. Ok. nebry @ 4360 - 4610 w/ 1 SPF, 20 8 gals acid. Frac w/115,681 gals of CBP @ 4330. Perf Middle Blinebro 2 gals acid. Frac w/116,177 gals of	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. lel, 145,378# 16/30 brady sand y @ 4050 - 4300 w/1 SPF, 26 hel, 144,525# 16/30 brady sand	, 31,332# 16/30 noles. , 31,556# 16/30	
13. Describe proposed or composition of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Co 3500 psi for 30 mins. Ok. nebry @ 4360 - 4610 w/ 1 SPF, 208 8 gals acid. Frac w/115,681 gals of CBP @ 4330. Perf Middle Blinebr 2 gals acid. Frac w/116,177 gals of CBP @ 4020. Perf Upper Blinebr	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. Sel, 145,378# 16/30 brady sand of @ 4050 - 4300 w/1 SPF, 26 hole, 144,525# 16/30 brady sand of @ 3765 - 3990 w/ 1 SPF, 26 hole).	, 31,332# 16/30 noles. , 31,556# 16/30 noles.	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constant of SEE RULE 1103. For Multiple Constant	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. Sholes. Sel, 145,378# 16/30 brady sand. J. @ 4050 - 4300 w/1 SPF, 26 holes. J. @ 3765 - 3990 w/ 1 SPF, 26 holes. J. W.	of proposed completion , 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900	
of starting any proposed or composition. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Frac	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constant SEE RULE 1103. For Multiple Constan	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. Sholes. Sel, 145,378# 16/30 brady sand y @ 4050 - 4300 w/1 SPF, 26 hel, 144,525# 16/30 brady sand w @ 3765 - 3990 w/ 1 SPF, 26 hel, 146,384# 16/30 brady sand 50 - 3500 w/1 SPF, 26 holes. 30 brady sand 18 505# 16/30	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constant of SEE RULE 1103. For Multiple Constant	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. Sholes. Sel, 145,378# 16/30 brady sand y @ 4050 - 4300 w/1 SPF, 26 hel, 144,525# 16/30 brady sand w @ 3765 - 3990 w/ 1 SPF, 26 hel, 146,384# 16/30 brady sand 50 - 3500 w/1 SPF, 26 holes. 30 brady sand 18 505# 16/30	of proposed completion , 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J.	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constant SEE RULE 1103. For Multiple Constan	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of holes. Sholes. Sel, 145,378# 16/30 brady sand y @ 4050 - 4300 w/1 SPF, 26 hel, 144,525# 16/30 brady sand w @ 3765 - 3990 w/ 1 SPF, 26 hel, 146,384# 16/30 brady sand 50 - 3500 w/1 SPF, 26 holes. 30 brady sand 18 505# 16/30	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' g 2/12/15	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constant SEE RULE 1103. For Multiple Constan	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes. Solution of the holes. Solution of the holes. Solution of the holes.	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop.	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J.	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Council SEE RULE 1103. Frac w/115,681 gals of CBP @ 4030. Perf Middle Blinebrough Goden Council SEE RULE 1103. Perf Upper Blinebrough Goden Council SEE RULE 1103. Perf Paddock @ 32 w/103,847 gals gel, 116,612# 16 out to PBTD 4886. SEE 6.5# tbg, EOT @ 4506. For Multiple Council SEE RULE 1103. For Multiple Counci	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes. Solution of the holes. Solution of the holes. Solution of the holes.	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date:	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Council SEE RULE 1103. Perf Middle Blinebro Council SEE RULE 1104. Frac w/116,177 gals of CBP @ 4020. Perf Upper Blinebro CBP @ 4020. Perf Upper Blinebro CBP @ 3530. Perf Paddock @ 32 w/103,847 gals gel, 116,612# 16 out to PBTD 4886. For SEE RULE 1103. For Multiple Council SEE RULE 1103. Rig Release Date:	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sholes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes.	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop.	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date:	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constant SEE RULE 1103. For Multiple Constan	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sholes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes.	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop.	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date:	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Council SEE RULE 1103. Perf Middle Blinebro Council SEE RULE 1104. Frac w/116,177 gals of CBP @ 4020. Perf Upper Blinebro CBP @ 4020. Perf Upper Blinebro CBP @ 3530. Perf Paddock @ 32 w/103,847 gals gel, 116,612# 16 out to PBTD 4886. For SEE RULE 1103. For Multiple Council SEE RULE 1103. Rig Release Date:	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sholes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes.	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop.	
of starting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date:	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Country. See Rule 1103. For Multiple Country	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sel, 145,378# 16/30 brady sand of the well of	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop.	
13. Describe proposed or compostarting any proposed we or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Fract 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date: 1 hereby certify that the information SIGNATURE	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constructions. Ok. See See See See Rule 1103. See See See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See See See See See See See Se	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes. Solvent Sel, 16/30 brady sand of the holes.	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop. APR 18 2012	
13. Describe proposed or compostarting any proposed work or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date: 1 hereby certify that the information SIGNATURE Type or print name Chasity Jac	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constructions. Ok. See See See See Rule 1103. See See See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See See See See See See See Se	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sel, 145,378# 16/30 brady sand of the well of the well bore diagram of the well bore diagram of the well bore diagram of the well and the well bore diagram of the well bore diagra	, 31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop. APR 18 2012 MOCD ARTESIA	
13. Describe proposed or compostarting any proposed was or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date: 1 hereby certify that the information SIGNATURE Type or print name Chasity Jac For State Use Only	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constructions. Ok. See See See See Rule 1103. See See See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See See See See See See See Se	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the properties of the	31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop APR 18 2012 MOCD ARTESIA	
13. Describe proposed or compostarting any proposed work or recompletion. 2/21/12 Drill out DVT. 2/24/12 Test casing to 2/27/12 Perf Lower Blir 3/1/12 Acidize w/3,26 siberprop. Set Acidize w/2,24 siberprop. Set Acidize w/2,31 siberprop. Set Acidize w/2,31 siberprop. Set gals acid. Frac 3/6/12 Drill out plugs. Clean 3/7/12 RIH w/133jts 2-7/8" J 3/8/12 RIH w/2-1/2"x2"x24' p Spud Date: 1 hereby certify that the information SIGNATURE Type or print name Chasity Jac	oleted operations. (Clearly state all pertinork). SEE RULE 1103. For Multiple Constructions. Ok. See See See See Rule 1103. See See See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See Rule 1103. For Multiple Constructions. See See See See Rule 1103. For Multiple Constructions. See See See See See See See See See Se	ent details, and give pertinent dates, in mpletions: Attach wellbore diagram of the holes. Sel, 145,378# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 144,525# 16/30 brady sand of the holes. Sel, 146,384# 16/30 brady sand of the holes. Solvent Sel, 16/30 brady sand of the holes.	31,332# 16/30 noles. , 31,556# 16/30 noles. , 31,090# 16/30 Acidize w/2,900 siberprop APR 18 2012 MOCD ARTESIA	