SUBMIT IN	ill" Use form 3150-3 (APD) f TRIPLIÇATE = Other/Instruc	DISTRICT/ ADTROV	OCD. 477 Hrunitör CA/Agreement fr 891000303X	<u></u>
기 Type of Well 같:ôi) Well : @ Gas Well 이미()			8. Well Name and No. ROKER LAKEJUNIT 18 1	WR 154H
2. Name of Operator XTO:PERMIAN OPERATING ULC E-Mail: Kelly kardos 3a. Address		LLYIKARDOS xtoenergyicom . Phone No (include area.code	9: API Weil No 30/015-46471-00-X1 , 10: Field and Pool of Explore	المرتبع بالمستحد
6401 HOLIDAY HILL ROAD BLDG 5		h: 432-620-4374	PURPLE/SAGE-WOU	FCAMP (
A Location of wein <i>Trootage Sec.</i> Sec 19 T24S R31E NENW 5 32:208481 N Lat, 103:81704	78FNL 2670FWL,		ICounty of Parish; State ÉDDY COUNITY, INM	
12: CHECK,THE A	PPROPRIATE BOX(ES) TO	ÎNDICATE NATURE O	E NOTICE, REPORT, OR OTHER D	ATA
TYPE OF SUBMISSION			ACTION	
<ul> <li>Notice of Intent</li> <li>Subsequent Report</li> <li>Final Abandonment Notice</li> </ul>	<ul> <li>Acidize</li> <li>Altor Casing</li> <li>Casing Repair</li> <li>Change Plans</li> <li>Convert to Injection</li> </ul>	<ul> <li>Despen</li> <li>Hydraulic Fracturing</li> <li>New Construction</li> <li>Plug and Abandon</li> <li>Plug Back</li> </ul>	Reclamation     Recomplete     Solution	Vater Shut Vell Integr Mer nge to Ofi
Attach the Bond under which the wo following completion of the involve	ally of fecomplete horizontally, give why will be performed of provide the d operations. If the operation results bandonment Notices must be filed o	tails, including estimated startin subsurface locations and mease Bond No. on file with BLM/BL/ in a multiple completion or reco	g date of any proposed work and approximate c red and true vertical depths of all pertinent mar Required subsequent reports must be filed wi mpletion in a new interval, a Porm 3160.4 mus ing reclamation, have been completed and the c	kers and zo ithin 30 day
XTO Permian Operating, LLC doing so, XTO will set each c well is static. With floats hold TA cap as per GE recommen wells on the pad. Once surfac the production hole on each c	asing string and ensure that t ng, no pressure on the cog ar dations, XTO will contact the 2 and intermediate strings ar	he well is cemented prope inulus, and the installation BLM to skid the rig to drill	ily and the of a 10K the remaining DEC 26	
Poker Låke Unit 18 TWR 154 Poker Lake Unit 18 TWR 124 Poker Lake Unit 18 TWR 104	H -30-015-46471 H - BLM APD approved APD H - BLM APD approved APD H - BLM APD approved APD	1D 10400042280 WO API 1D 10400042275 WO API	Number Number SFE ATTACHED CONDITIONS O	FOR F AP
$\bigcap$		the second state of the se		<u>an an a</u>
14: I liereby certify that the foregoing i	s true and contest Electron of Submission #496 For XTO PERMIAN hitted to AFMSS for procession	OPERATING LLC, sent to t y by JENNIFER SANCHEZ of	he Carlsbad	وه کې مېرو کې د وه و داو چې و کې د و
14: I hereby certify that the foregoing i	s true and correct Electron of Submission, #496 For XTO PERMIAN nitted to AFMSS for procession ARDOS	OPERATING LLC, sent to t y by JENNIFER SANCHEZ of	he Carlsbad n 12/17/2019 (20JAS0033SE) ATORY COORDINATOR APPROVED	
14: 1 hereby certify that the foregoing i Comi Name (Printed Typed) - KELLY, K	s true and configure Electron CSubmission #496 For XTO PERMIAN nitted to AFMSS for processin ARDOS	OPERATING LLC, sent to to by JENNIFER SANCHEZ (	he Carlsbad n 12/17/2019 (20JAS0033SE) ATORY COORDINATOR APPROVED	
14: 1 hereby certify that the foregoing i Comi Name (Printed Typed) - KELLY, K	s true and correct Electron CSubmission #496 For XTO PERMIAN nitted to AFMSS for processing ARDOS Submission THIS SPACE FOR dial Approvel of this notice does not wiable und to these renty in the sub	OPERATING LLC, sent to to to y JENNIFER SANCHEZ to the total sent to the total sent to to the total sent total	he Carlsbad n 12/17/2019 (20JAS0033SE) ATORY COORDINATOR APPROVED	Date:

# Revisions to Operator-Submitted EC Data for Sundry Notice #496113

Kare -

## Operator Submitted

APDCH Sundry Type Lease:

Agreement NMNM71016X Operator XTO PERMIAN OPE HOLIDAY

Admin Contact Ph: 432 620 4374

Tech Contact - 7 KEULY KARDO Y COORDINATOR ardos@xtoenergy

Location: State County PURPLE SAGE WOLFGAMP Field/Pool: 44.这点气

Well/Facility POKER LAKE UNI Mer NMP NENW 578ENL 26

素素、管理 a shire

#### BLM Revised (AFMSS)

#891000303X (NMNM71016X) / 5 -

**V**COORDINATOR

TORY COORDINATOR Ph: 432-620-4374

🕹 EDD) 師神機法 PURPLE SAGE WOLFCAMP (GAS POKER LAKE UNIT 18 TWR 154H 2670FW 32 208481 N Lat. 103.8

# PECOS DISTRICT DRILLING CONDITIONS OF APPROVAL

<b>OPERATOR'S NAME:</b>	XTO Permian Operating, LLC.
LEASE NO.:	NMNM-0025533
WELL NAME & NO.: '	Poker Lake Unit 18 TWR 154H
SURFACE HOLE FOOTAGE:	
<b>BOTTOM HOLE FOOTAGE</b>	0200' FSL & 2430' FWL Sec. 30, T. 24 S., R 31 E.
LOCATION:	Section 19, T. 24 \$., R 31 E., NMPM
COUNTY:	Eddy County, New Mexico

#### **Commercial Well Determination**

A commercial well determination shall be submitted after production has been established for at least six months.

#### **Unit Wells**

The well sign for a unit well shall include the unit number in addition to the surface and bottom hole lease numbers. This also applies to participating area numbers. If a participating area has not been established, the operator can use the general unit designation, but will replace the unit number with the participating area number when the sign is replaced.

## A. DRILLING OPERATIONS REQUIREMENTS

The BLM is to be notified in advance for a representative to witness:

- a. Spudding well (minimum of 24 hours)
- b. Setting and/or Cementing of all casing strings (minimum of 4 hours)
- c. BOPE tests (minimum of 4 hours)

#### **Eddy County**

Call the Carlsbad Field Office, 620 East Greene St., Carlsbad, NM 88220, (575) 361-2822

- 1. Hydrogen Sulfide (H2S) monitors shall be installed prior to drilling out the surface shoe. If H2S is detected in concentrations greater than 100 ppm, the Hydrogen Sulfide area shall meet Onshore Order 6 requirements, which includes equipment and personnel/public protection items. If Hydrogen Sulfide is encountered, provide measured values and formations to the BLM.
- Unless the production casing has been run and cemented or the well has been properly plugged, the drilling rig shall not be removed from over the hole without prior approval. If the drilling rig is removed without approval an Incident of Non-Compliance will be written and will be a "Major" violation.

- 3. The operator has proposed to drill multiple wells utilizing a skid/walking rig. Operator shall secure the wellbore on the current well, after installing and testing the wellhead, by installing a blind flange of like pressure rating to the wellhead and a pressure gauge that can be monitored while drilling is performed on the other well.
- 4. Floor controls are required for 3M or Greater systems. These controls will be on the rig floor, unobstructed, readily accessible to the driller and will be operational at all times during drilling and/or completion activities. Rig floor is defined as the area immediately around the rotary table; the area immediately above the substructure on which the draw works is located, this does not include the dog house or stairway area.
- 5. The record of the drilling rate along with the GR/N well log run from TD to surface (horizontal well – vertical portion of hole) shall be submitted to the BLM office as well as all other logs run on the borehole 30 days from completion. If available, a digital copy of the logs is to be submitted in addition to the paper copies. The Rustler top and top and bottom of Salt are to be recorded on the Completion Report.

## B. CASING

Changes to the approved APD casing program need prior approval if the items substituted are of lesser grade or different casing size or are Non-API. The Operator can exchange the components of the proposal with that of superior strength (i.e. changing from J-55 to N-80, or from 36# to 40#). Changes to the approved cement program need prior approval if the altered cement plan has less volume or strength or if the changes are substantial (i.e. Multistage tool, ECP, etc.). The initial wellhead installed on the well will remain on the well with spools used as needed.

Centralizers required on surface casing per Onshore Order 2.III.B.1.f.

### Wait on cement (WOC) for Water Basin:

After cementing but before commencing any tests, the casing string shall stand cemented under pressure until both of the following conditions have been met: 1) cement reaches a minimum compressive strength of 500 psi at the shoe, 2) until cement has been in place at least <u>8 hours</u>. WOC time will be recorded in the driller's log. See individual casing strings for details regarding lead cement slurry requirements.

Provide compressive strengths including hours to reach required 500 pounds compressive strength prior to cementing each casing string. Have well specific cement details onsite prior to pumping the cement for each casing string. No pea gravel permitted for remedial or fall back remedial without prior authorization from the BLM engineer.

Possibility of water flows in the Salado and Castile. Possibility of lost circulation in the Red Beds, Rustler, and Delaware. Abnormal pressure may be encountered in the 3rd Bone Spring and all subsequent formations.

- 1. The 18-5/8 inch surface casing shall be set at approximately 720 feet (in a competent bed below the Magenta Dolomite, which is a Member of the Rustler, and if salt is encountered, set casing at least 25 feet above the salt) and cemented to the surface.
  - a. If cement does not circulate to the surface, the appropriate BLM office shall be notified and a temperature survey utilizing an electronic type temperature survey with surface log readout will be used or a cement bond log shall be run to verify the top of the cement. Temperature survey will be run a minimum of six hours after pumping cement and ideally between 8-10 hours after completing the cement job.
  - b. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry.
  - c. Wait on cement (WOC) time for a remedial job will be a minimum of 4 hours after bringing cement to surface or 500 pounds compressive strength, whichever is greater.
  - d. If cement falls back, remedial cementing will be done prior to drilling out that string.
- 2. The minimum required fill of cement behind the 1/3-3/8 inch intermediate casing is:

Cement to surface. If cement does not circulate see B.1.a, c-d above.

Formation below the 13-3/8" shoe to be tested according to Onshore Order 2.III.B.1.i. Test to be done as a mud equivalency test using the mud weight necessary for the pore pressure of the formation below the shoe (not the mud weight required to prevent dissolving the salt formation) and the mud weight for the bottom of the hole. Report results to BLM office. 9-5/8" Intermediate casing shall be kept fluid filled while running into hole to meet BLM minimum collapse requirements.

3. The minimum required fill of cement behind the 9-5/8 inch intermediate casing is:

Operator has proposed DV tool at depth of 4200', but will adjust cement proportionately if moved. DV tool shall be set a minimum of 50' below previous shoe and a minimum of 200' above current shoe. Operator shall submit sundry if DV tool depth cannot be set in this range. If an ECP is used, it is to be set a minimum of 50' below the shoe to provide cement across the shoe. If it cannot be set below the shoe, a CBL shall be run to verify cement coverage.

- a. First stage to DV tool:
- Cement to circulate. If cement does not circulate, contact the appropriate BLM office before proceeding with second stage cement job. Operator should have plans as to how they will achieve circulation on the next stage. Excess calculates to 16% - Additional cement may be required.

b. Second stage above DV tool:

Cement to surface. If cement does not circulate, contact the appropriate BLM office.

Formation below the 9-5/8" shoe to be tested according to Onshore Order 2.III.B.1.i. Test to be done as a mud equivalency test using the mud weight necessary for the pore pressure of the formation below the shoe (not prevent dissolving the salt formation) and the mud hole. Report results to BLM office.

Centralizers required on horizontal leg, must be type for horizontal service and a minimum of one every other joint.

5-1/2" Production casing shall be kept fluid filled while running into hole to meet BLM minimum collapse requirements.

4. The minimum required fill of cement behind the 5-1/2 inch production casing is:

Cement should tie-back at least 200 feet into previous casing string. Operator shall provide method of verification.

5. If hardband drill pipe is rotated inside casing, returns will be monitored for metal. If metal is found in samples, drill pipe will be pulled and rubber protectors which have a larger diameter than the tool joints of the drill pipe will be installed prior to continuing drilling operations.

### C. PRESSURE CONTROL

- 1. All blowout preventer (BOP) and related equipment (BOPE) shall comply with well control requirements as described in Onshore Oil and Gas Order No. 2 and API 53.
- 2. Variance approved to use flex line from BOP to choke manifold. Check condition of flexible line from BOP to choke manifold, replace if exterior is damaged or if line fails test. Line to be as straight as possible with no hard bends and is to be anchored according to Manufacturer's requirements. The flexible hose can be exchanged with a hose of equal size and equal or greater pressure rating. Anchor requirements, specification sheet and hydrostatic pressure test certification matching the hose in service, to be onsite for review. These documents shall be posted in the company man's trailer and on the rig floor. If the BLM inspector questions the straightness of the hose, a BLM engineer will be contacted and will review in the field or via picture supplied by inspector to determine if changes are required (operator shall expect delays if this occurs).
- 3. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the surface casing shoe shall be **2000 (2M)** psi.
- 4. Operator has proposed a multi-bowl wellhead assembly. This assembly will only be tested when installed on the 13-3/8" intermediate casing. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the 13-3/8" intermediate casing shoe shall be 10,000 (10M) psi.
  - a. Wellhead shall be installed by manufacturer's representatives, submit documentation with subsequent sundry.
  - b. If the welding is performed by a third party, the manufacturer's representative shall monitor the temperature to verify that it does not exceed the maximum temperature of the seal.
  - c. Manufacturer representative shall install the test plug for the initial BOP test.
  - d. Operator shall perform the 9-5/8" intermediate casing integrity test to 70% of the casing burst. This will test the multi-bowl seals.
  - e. If the cement does not circulate and one inch operations would have been possible with a standard wellhead, the well head shall be cut off, cementing operations performed and another wellhead installed.

Variance approved to use a 5M annular. The annular must be tested to full working pressure (5000 psi.)

10M system requires an HCR valve, remote kill line and annular to match. The remote kill line is to be installed prior to testing the system and tested to stack pressure.

- 5. The appropriate BLM office shall be notified a minimum of 4 hours in advance for a representative to witness the tests.
  - a. In a water basin, for all casing strings utilizing slips, these are to be set as soon as the crew and rig are ready and any fallback cement remediation has been done. The casing cut-off and BOP installation can be initiated four hours after installing the slips, which will be approximately six hours after bumping the plug. For those casing strings not using slips, the minimum wait time before cut-off is eight hours after bumping the plug. BOP/BOPE testing can begin after cut-off or once cement reaches 500 psi compressive strength (including lead when specified), whichever is greater. However, if the float does not hold, cut-off cannot be initiated until cement reaches 500 psi compressive strength (including lead when specified).
  - b. The tests shall be done by an independent service company utilizing a test plug **not a cup or J-packer**.
  - c. The test shall be run on a 5000 psi chart for a 2-3M BOP/BOP, on a 10000 psi chart for a 5M BOP/BOPE and on a 15000 psi chart for a 10M BOP/BOPE. If a linear chart is used, it shall be a one hour chart. A circular chart shall have a maximum 2 hour clock. If a twelve hour or twenty-four hour chart is used, tester shall make a notation that it is run with a two hour clock.
  - d. The results of the test shall be reported to the appropriate BLM office.
  - e. All tests are required to be recorded on a calibrated test chart. A copy of the BOP/BOPE test chart and a copy of independent service company test will be submitted to the appropriate BLM office.
  - f. The BOP/BOPE test shall include a low pressure test from 250 to 300 psi. The test will be held for a minimum of 10 minutes if test is done with a test plug and 30 minutes without a test plug. This test shall be performed prior to the test at full stack pressure.
  - g. BOP/BOPE must be tested by an independent service company within 500 feet of the top of the **Wolfcamp** formation if the time between the setting of the intermediate casing and reaching this depth exceeds 20 days. This test does not exclude the test prior to drilling out the casing shoe as per Onshore Order No. 2.

#### D. DRILLING MUD

Mud system monitoring equipment, with derrick floor indicators and visual and audio alarms, shall be operating before drilling into the **Wolfcamp** formation, and shall be used until production casing is run and cemented.

Page 6 of 7

# E. DRILL STEM TEST

If drill stem tests are performed, Onshore Order 2.III.D shall be followed.

# F. WASTE MATERIAL AND FLUIDS

All waste (i.e. drilling fluids, trash, salts, chemicals, sewage, gray water, etc.) created as a result of drilling operations and completion operations shall be safely contained and disposed of properly at a waste disposal facility. No waste material or fluid shall be disposed of on the well location or surrounding area.

Porto-johns and trash containers will be on-location during fracturing operations or any other crew-intensive operations.

# JAM 121819