

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN REPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-029418(b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Lea "C"

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Grayburg-Jackson

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 11-17S-31E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Skelly Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 1351, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

Unit Letter B, 660' FWL and 1980' FWL, Section 11-17S-31E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3968' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Deepen and install liner

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Development drilling on this lease has shown that deeper commercial pay zones are present. We propose to deepen this well in the San Andres formation and install casing liner as follows:

- 1) Move in pulling unit. Pull rods and tubing.
- 2) Drill cement out of 5-1/2" casing and open hole from 3645' FETD to original TD 3759'.
- 3) Drill new hole 3759-3974'.
- 4) Run 4" OD liner. Set top of liner between 3635' and 3664', set bottom at 3974'.
- 5) Cement liner and WOC 24 hours.
- 6) Drill out to top of liner and pressure test.
- 7) Drill out inside liner to 3960'.
- 8) Run Gamma Ray-Neutron Log from approximately 3450' to FETD.
- 9) Perforate 4" OD liner as indicated by log.
- 10) Treat new perforations with 4000 gallons of 15% NE acid.
- 11) Run tubing and swab test.
- 12) Run pump and rods. Return well to production.

18. I hereby certify that the foregoing is true and correct

SIGNED

D. R. Crow

TITLE

Lead Clerk

DATE

Nov. 5, 1973

(This space for Federal or State office use)

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NOV 7 - 1973

R. L. BEEKMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side