

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division
811 S. 1st Street
Artesia, NM 88210-2834

FORM APPROVED
Budget Bureau No. 1004-0135
Expires March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
DEVON ENERGY CORPORATION (NEVADA)

3. Address and Telephone No.
20 NORTH BROADWAY, SUITE 1500, OKLAHOMA CITY, OKLAHOMA 73102 (405) 235-3611

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
660' FNL & 660' FEL of Section 20-T17S-R31E

5. Lease Designation and Serial No.
LC-029395B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Turner "B" #9

9. API Well No.
30-015-05281

10. Field and Pool, or Exploratory Area
Grayburg-Jackson Field

11. County or Parish, State
Eddy County, NM

CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION	
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input checked="" type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other _____	<input type="checkbox"/> Dispose Water
<small>(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)</small>		
13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*		

Convert to a water injection well as follows:

1. Clean out wellbore to TD.
2. Selectively perforate the interval 2700' - 3480' (OA).
3. RIH with Baker Loc-Set packer on 2 3/8" (IPC) tubing and set at 2650'.
4. Inject through perforations 2700' - 3480' (OA).

**SUBJECT TO
LIKE APPROVAL
BY STATE**

NMOCD

DEC 12 '96

O. C. D.
ARTESIA, OFFICE

14. I hereby certify that the foregoing is true and correct

Signed Charles H. Carleton
(This space for Federal or State office use)

Charles H. Carleton
Title Sr. Engineering Tech.

Date 11/25/96

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA
Conditions of approval, if any:

Title PETROLEUM ENGINEER

Date 11/25/96