

**UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT**

SUBMIT IN TRIPlicate
(Other Instructions on
reverse side)

Oil Cons.
N.M. Div-Dist 2
Budget Bureau No. 1004-0135
1301 W. Grand Avenue
Artesia, NM 88210

dsf

SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT - " for such proposals.)		5. LEASE DESIGNATION AND SERIAL NO. LC-029419-A	
		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER TA		7. UNIT AGREEMENT NAME Skelly Unit	
2. NAME OF OPERATOR The Wisner Oil Company		8. WELL NO. 3	
3. ADDRESS OF OPERATOR P.O. Box 2568 Hobbs, New Mexico 88240 (505) 392-9797		9. API WELL NO. 30-015-05347	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FNL & 660' FWL Unit D		10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 7-Rivers-QN-GB-SA???	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 22-T17S-R31E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3852' DF	12. COUNTY OR PARISH Eddy County	13. STATE NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

<p align="center">NOTICE OF INTENTION TO:</p> <p>TEST WATER SHUT OFF <input type="checkbox"/></p> <p>FRACTURE TREAT <input type="checkbox"/></p> <p>SHOOT OR ACIDIZE <input type="checkbox"/></p> <p>REPAIR WELL <input type="checkbox"/></p> <p>(Other) <u>Plug & Abandon</u></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>MULTIPLE COMPLETE <input type="checkbox"/></p> <p>ABANDON* <input type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p>	<p align="center">SUBSEQUENT REPORT OF:</p> <p>WATER SHUT-OFF <input type="checkbox"/></p> <p>FRACTURE TREATMENT <input type="checkbox"/></p> <p>SHOOTING OR ACIDIZING <input type="checkbox"/></p> <p>(Other) _____</p> <p>REPAIRING WELL <input type="checkbox"/></p> <p>ALTERING CASING <input type="checkbox"/></p> <p>ABANDONMENT * <input type="checkbox"/></p> <p>(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)</p>
---	--

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser request approval to plug and abandon the well by the procedure listed below.

w/Cement Circulated *w/Cement Circulated*

SURFACE CASING: 13-3/8" SET @ *211'* PRODUCTION CASING: 9-5/8" @ 3784' PERFS: 2224'-3746'

1. TIH w/tbg. & tag cmt. @ CBP 2150' *w/35' Cement On Top*
2. Circulate abandonment mud to surface.
3. POH to 1600' & set *100'* plug. # F/1500-1600'
4. Tag cmt. Plug.
5. POH to 600' & set *100'* plug. # F/500-600'
6. Tag cmt plug.
7. Set 50' cmt. plug @ surface. *F/0-50'*
8. Install dry hole marker.
9. Clean location. RDMO.

Top Salt 568'
Base Salt 1560'

Set 100' Plug F/150-250'



18. I hereby certify that the foregoing is true and correct.

SIGNED *M. Jones* TITLE Production Tech II DATE September 28, 2001

(This space for Federal or State Approval)

APPROVED BY DAVID R. GLASS TITLE _____ DATE _____

CONDITIONS OF APPROVAL IF ANY: OCT 5 2001

*See Instruction On Reverse Side

RECEIVED
MAY 19 1966
100