

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. Oil & Gas Division  
SUBMITTAL INSTRUCTIONS: Budget Bureau No. 1004-0135  
(Other Instructions on Reverse Side) Expires August 31, 1985

Artesia, NM 87003  
LEASE, DEED, EASEMENT, AND SERIAL NO.  
LC-029419A

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL ☐ GAS ☐ OTHER ☐  
WELL WELL Water Injection

2. NAME OF OPERATOR  
The Wiser Oil Company

3. ADDRESS OF OPERATOR  
P.O. Box 2568 Hobbs, New Mexico 88241

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

1980' FSL & 1980' FWL  
Unit K

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME  
Skelly Unit

8. WELL API NO.  
30-015-05352

9. WELL NO.  
53

10. FIELD AND POOL, OR WILDCAT  
Grayburg Jackson Seven Rivers QN GB SA

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
Sec. 22-T17S-R31E

14. PERMIT NO

15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
3843' DF

12. COUNTY OR PARISH  
Eddy

13. STATE  
NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF ☐ PULL OR ALTER CASING ☐  
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐  
SHOOT OR ACIDIZE ☐ ABANDON\* ☒  
REPAIR WELL ☐ CHANGE PLANS ☐  
(Other) Plug and Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐  
FRACTURE TREATMENT ☐ ALTERING CASING ☐  
SHOOTING OR ACIDIZING ☐ ABANDONMENT \* ☐  
(Other) ☐  
(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser requests approval to plug and abandon the well by the procedure listed below.

1. POH w/production equipment. TIH w/CIBP & set @ 3000'. Current perforations @ 3041'-3429'.
2. Dump 50 sks. cmt. on CIBP. Tag cmt. plug.
3. Circulate abandonment mud.
4. Set 50 sx. plug @ 1700'. Tag cmt. plug.
5. Perforate casing @ 710' & circulate cmt. to surface. Set 10 sxs. cmt. @ 50' from surface.
6. Install dry hole marker.
7. Clean location.

18. I hereby certify that the foregoing is true and correct.

SIGNED D. M. Jones TITLE Production Superintendent DATE August 21, 2000

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

\*See Instruction On Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

