

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

NM OIL CONS COMMISSION  
Drawer DD  
Artesia, NM 88210

FORM APPROVED  
Budget Bureau No. 1004 0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Anadarko Petroleum Corp.

3. Address and Telephone No.

PO Drawer 130, Artesia, NM 88211-0130 (505) 677-2411

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 1980' FWL, Section 15, T17S, R30E.

5. Lease Designation and Serial No.

NM 074935

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Loco Hills "A" Fed. #3

9. API Well No.

30-015-20579

10. Field and Pool, or Exploratory Area

Grayburg-Jackson-Queen-

11. County or Parish, State

San Andres

Eddy County, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other  
☐ Change of Plans  
☐ New Construction  
☐ Non Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. RUPU. TOH with rods and tbq.
2. Set CIBP at 2585' on tbq and circulate hole with salt gel mud. TOH with tbq.
3. RU wireline and spot 35' cement on CIBP @ 2585' using a dumpbailer. This plug covers Grayburg Formation top.
4. Set CIBP at 1280' and spot 100' cement on top of it. This plug isolates base of salt and squeeze holes at 1270'.
5. Set CIBP at 520' and spot 35' cement on top of it. This plug isolates top of salt.
6. Spot 100' cement from 457' up to 357'. This plug covers 8 5/8" casing shoe.
7. Spot a 50' surface plug.
8. Cut off all casing and anchors below ground level; set dry hole marker; rip and reseed location as per BLM rules and regulations.

14. I hereby certify that the foregoing is true and correct

Signed Mike Brumwell

Title Field Foreman

Date 5-21-93

(This space for Federal or State office use)

Approved by (ORIG. SGD.) JOE G. LARA

Title Petroleum Engineer

Date JUN 28 1993

Conditions of approval, if any:

2-11-93

ANADARKO

P.O. DRAWER 130

ARTESIA, NEW MEXICO 88210

(505) 882-1100

**Anadarko**

Loco Hills Federal "A" 3-15

