

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy Minerals and Natural Resources Department

Form C-103
Revised 1-1-89
c/s 11
v/r

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.	30-015-26967
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	E-9891

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	7. Lease Name or Unit Agreement Name West Dayton AJR State Com
2. Name of Operator YATES PETROLEUM CORPORATION	8. Well No. 1
3. Address of Operator 105 South 4th St., Artesia, NM 88210	9. Pool name or Wildcat Dayton Strawn
4. Well Location Unit Letter <u>N</u> : <u>990</u> Feet From The <u>South</u> Line and <u>2310</u> Feet From The <u>West</u> Line Section <u>16</u> Township <u>18S</u> Range <u>26E</u> NMPM <u>Eddy</u> County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3366' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: _____ <input type="checkbox"/>		OTHER: _____ <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Retrieve RBP at 8254'.
2. Set CIBP at 8175' and cap with 35' of cement.
3. Cut and pull 5-1/2" casing at 6300' (top of cement indicated by tag).
4. Set a 100' cement plug across 5-1/2" casing stub. WOC. Tag plug.
5. Set a 100' cement plug across the top of the Wolfcamp at 5726'.
6. Set a 100' cement plug across the top of the Glorieta at 2326'.
7. Set a 100' cement plug across the 8-5/8" casing shoe at 1310'.
8. Set a 100' cement plug across the 13-3/8" casing shoe at 518'.
9. Set a 10 sack surface plug.
10. Install regulation abandonment marker.

Plugging mud between plugs. > # 100' Plug @ 4400'.

RECEIVED
APR 15 1996
OIL CON. DIV.
DIST. 2

NOTIFY OCD-ARTESIA (505-748-1283) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE 4-11-96

TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE APR 22 1996

CONDITIONS OF APPROVAL, IF ANY:

ORIGINAL SIGNED BY TIM W. GUM
DISTRICT II SUPERVISOR