

Form 3160-5
(July 1989)
(Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVING
OFFICE FOR NUMBER
OF COPIES REQUIRED
(Other instructions on reverse
side)

BLM Roswell District
Modified Form No.
NM060-3160-4

5. LEASE DESIGNATION AND SERIAL NO.
LC-029287-A

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR SOUTHLAND ROYALTY COMPANY		8. FARM OR LEASE NAME SHUGART "A"	
3. ADDRESS OF OPERATOR P.O. Box 51810, Midland, TX 79710-1810		3a. AREA CODE & PHONE NO. 915-688-6906	9. WELL NO. 1
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface M, 330' FSL & 990' FWL		10. FIELD AND POOL, OR WILDCAT SHUGART (Y-7R-QN-GB)	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 29, T-18-S, R-31-E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) NOT AVAILABLE	12. COUNTY OR PARISH EDDY	13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

☐

PULL OR ALTER CASING

☐

FRACTURE TREAT

☒

MULTIPLE COMPLETE

☐

SHOOT OR ACIDIZE

☒

ABANDON*

☐

REPAIR WELL

☐

CHANGE PLANS

☐

(Other) ADD YATES PERFS, ACID., & FRAC.

☒

WATER SHUT-OFF

☐

REPAIRING WELL

☐

FRACTURE TREATMENT

☐

ALTERING CASING

☐

SHOOTING OR ACIDIZING

☐

ABANDONMENT*

☐

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

ADD YATES PERFS, ACIDIZE AND FRACTURE STIMULATE

RIH W/BIT & SCRAPER TO CHECK FOR OBSTRUCTIONS. RIH W/GR-CCL TOOL, LOG F/3600'+-2000'. PERFORATE YATES F/2594'-2620' 2 SPF, 28 HOLES. SET RBP @2700'+ AND TEST TO 3500 PSI. SET PACKER AT 2500'+. BREAKDOWN PERFS W/2 DRUMS OF TRETOLITE SP358 25% SOLUTION MIXED W/330 GALLONS 2% KCL. FOLLOW W/1000 GALLONS 7-1/2% NEFE HCL ACID. SPACE OUT 42 - 7/8" RCNBS. FRACTURE STIMULATE YATES W/14, 500 GALLONS 40# BORATE X-LINKED GEL & 44,000# 12/20 BRADY SD. SI WELL OVERNIGHT. FLOW WELL BACK UNTIL IT DIES. RIH W/2-3/8" PRODUCTION TBG, SET MA AT 2550'+. RIH W/2" X 1.5" X 10' PUMP AND 3/4" RODS. PUT WELL ON PRODUCTION.

18. I hereby certify that the foregoing is true and correct			
SIGNED	<u>Maria L. Perez</u>	TITLE	<u>PRODUCTION ASST.</u>
		DATE	<u>12-30-91</u>
(This space for Federal or State office use)			
APPROVED BY		TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:			

*See Instructions on Reverse Side