

N. M. O. C. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-064577A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

B. I. Hanson Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Shugart Yates Seven Rivers
Queen Grayburg

11. SEC., T., E., M., OR BLK. AND
SURVEY OR AREA

3, 19S, 31E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

TEXACO Inc. ✓

3. ADDRESS OF OPERATOR

P.O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

2,310' FSL & 2,310' FWL of Sec. 3, T-19-S, R-31-E, Unit
Letter K

14. PERMIT NO.

Regular

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3,607 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Pull rods, pump and tubing. Run RBP and set at 2,800'. Dump 10' of sand on top of plug.
2. Perforate 5-1/2" casing w/1 JSPF from 2,693' to 2,717'. Acidize w/500 gals HF acid (3%) and HCL acid (12%). Swab test to determine productive capacity.
3. If necessary frac as follows: pump 2,000 gals gelled brine water pad, 2,000 gals gelled brine water w/ 1/2# per gal 20-40 sand, 2,000 gals gelled brine w/ 1# per gal 20-40 sand, 2,000 gals gelled brine w/ 1/4# per gal 20-40 sand and 2,000 gals gelled brine w/1-1/2# per gal 20-40 sand. Flush with 1,500 gals brine.
4. Swab, test, pull RBP and set CIBP at 3,350' and cap with 20' cement. Put well on production.

RECEIVED

NOV 27 1972

O. C. C.
ARTESIAL OFFICE

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Assistant District
Superintendent

DATE November 22, 1972

(This space for Federal or State office use)

TITLE

DATE

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

NOV 24 1972
R. L. BECKMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

