

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

11-5-93

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well  
☒ Oil Well ☐ Gas Well ☒ Other **WATER INJECTION WELL**

2. Name of Operator  
**Southland Royalty Company**

3. Address and Telephone No.  
**P.O. Box 51810 Midland, TX 79710**

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
**2310' FNL, 1650' FWL**  
**Sec. 29, T18S, R31E**  
**Eddy County, New Mexico**

5. Lease Designation and Serial No.  
**LC-029387C**

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.  
**Kenwood No. 3**

9. API Well No.  
**30-015-10095**

10. Field and Pool, or Exploratory Area  
**Shugart (Y,7R,QN,GB)**

11. County or Parish, State  
**Eddy County**  
**New Mexico**

**12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

**TYPE OF SUBMISSION**

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

**TYPE OF ACTION**

- ☐ Abandonment  
☒ Recompletion  
☒ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other **PLUG BACK FROM**  
**GRAYBURG TO YATES ZONE.**
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☒ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*  
**NU BOPE. RIH w/ bit and casing scraper on 2-3/8" tubing to 3775'. POOH w/ tubing and bit.**

**GIH w/ cement retainer on 2-3/8" tubing setting retainer at +/- 3100'.**

**RU cementing equipment. Squeeze perfs 3,774'-3,823' w/ 150 sx Class C cement. Cap CICR w/ 35' cement.**

**POOH w/ tubing. GIH and perf Yates +/-2450'-2550'. POOH w/ perforating gun.**

**GIH w/ 2-3/8" tubing and tension packer to 2350'. Circulate hole w/ packer fluid. Set packer @ 2350'.**

**Perform casing integrity pressure test to 500 psi and provide pressure chart.**

**ND BOPE.**

**Equip well for water injection. Commence water injection.**

**If necessary, acidize well w/ 1,500 gals acid.**

14. I hereby certify that the foregoing is true and correct

Signed Maria L. Perez

Title **Production Assistant**

Date 11-5-93

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title \_\_\_\_\_

Date \_\_\_\_\_