

Barbara Federal No. 3

Pg 2

Spot 13 sxs plug from 380'-480'. Place 1 sxc nt plug
from surface to 30'. Cut and install off. re install 18A
marker.