

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

RECEIVED LEASE

FEDERAL LC 070220

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
BIG EDDY UNIT

8. FARM OR LEASE NAME
BIG EDDY UNIT

9. WELL NO.
10

10. FIELD OR WILDCAT NAME
BIG EDDY (STRAWN)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
SEC. 19, T20S, R31E

12. COUNTY OR PARISH
EDDY

13. STATE
NEW MEXICO

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3549' KDB

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐

2. NAME OF OPERATOR
PERRY R. BASS

3. ADDRESS OF OPERATOR
P.O. BOX 2760, MIDLAND, TX 79702

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1656' FSL & 1972' FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☒
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☐
(other) ☐

SUBSEQUENT REPORT OF:

☐
☐
☐
☐
☐
☐
☐
☐
☐

RECEIVED

MAY 11 1983

DL & SAC

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

ROSWELL, NEW MEXICO

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*
Work will begin upon approval:

1. Set cement retainer at +11,300'. Cement squeeze producing interval 11364-11396'.
2. Locate higher casing leak using packer.
3. Set cement retainer 50' above casing leak. Pump cement through and squeeze cement into casing leak.
4. Drill out cement retainers and cement to 11385'.
5. Spot acid and perforate interval 11364-11380' (17 holes) using casing gun.
6. RIH with packer, SN and 2-3/8" production tubing. Set packer at 11330'.
7. Acidize with 4000 gals 20% HCl acid.
8. Flow or swab well to production

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED John D. Rodgers TITLE Sr. Production Engr. DATE May 10, 1983

(Orig. Sgd.) **APPROVED** (This space for Federal or State office use)

APPROVED BY PETER W. CHESTER

CONDITIONS OF APPROVAL, IF ANY: _____ TITLE _____ DATE _____

MAY 28 1983

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.