

22 - 22

Plugging Procedure 8-25-94

Carl Schelling or
Mahon State #1

Called by Owen Pocket ; ~~PK~~

⑤ 10
in top.

13 3/8 - 200

④ 100 - 1750 -
1850' Tag

8 5/8" to 1800

③ 100 above
Base needed
if plug may
stop plug care of it.

② 50 in + out
of stub.
Tag

① CIBP - at 6400
+ 35'
6453
6514

+ 400'

450 sks behind 4 1/2

6699

4 1/2 to ~~7500~~

Will file C-103 for approval
prior to plugging.