

Lone Tree Fed Comm #1 PTA Procedure

1. C2BP @ 6575' w/ 35' cut
 2. Pull stretch test casing at fence point. Pick & lay down casing
 3. Set 25 3x plug in casing stub. 50' in / 50' out. Tag plug
 4. 35 3x plug @ 5450' top of Barn Springs
 5. 35 3x plug @ 2545' top of Delaware
 6. 35 3x plug @ 2300' Tag plug
 7. 35 3x plug @ 700'
 8. 10 3x surface plug. Weld on plate & install PTA marker
- * NOTE: mud will be placed between all plugs.
- Cutoff anchors & plug locations