

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004 0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

(505) 768-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Surface: 1980' FNL & 910' FWL (Unit E, SWNW)

Bottom: 1980' FNL & 2405' FEL (Unit G, SWNE)

Section 27-T20S-R29E

RECEIVED

OIL CON. DIV.
DIST. 1

5. Lease Designation and Serial No.

NM-83068

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Zinnia Federal Unit #1

9. API Well No.

30-015-27939

10. Field and Pool, or Exploratory Area

Undesignated Delaware

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to ^{temporarily} abandon perforations 9909-10216' (Wolfcamp) and 10965-10988' (Strawn) and recomplete to Delaware as follows:

1. TOOH with tubing and sub pump.
2. Set RBP at 9800' to abandon perforations 9902-10216' and 10965-10988'.
3. Perforate 3900-3933' w/20 holes (Delaware). Acidize and frac as necessary.
4. Swab test. Put well on pump.

14. I hereby certify that the foregoing is true and correct

Signed Rusty Kline

Title Operations Technician

Date June 7, 1996

(This space for Federal or State office use)

Approved by (ONG. SGP) JOE G. LARA

Title PETROLEUM ENGINEER

Date 7/5/96

Conditions of approval, if any: