

Exhibit "I"

Marathon Oil Company

SPILL PREVENTION CONTROL AND COUNTERMEASURE PLAN (SPCC PLAN)

Marathon Oil Company has pollution prevention, good housekeeping, safety and fire prevention policies that are to be followed at all times. All company employees, contractors and subcontract personnel are to observe safe working practices and prevent pollution to the maximum extent possible.

In the event of an emergency, spill, fire, explosion or blowout, personal injuries, property or equipment damage, call **MARATHON OIL COMPANY @ 915-559-9339**

Prior to drilling, certain measures should be taken:

1. Use impervious materials to build the location and the reserve pit.
2. Ditch the outline of the rig toward the reserve pit.
3. Place sumps on each end of the rig to catch any free oil or debris from entering the reserve pit.
4. Keep materials on location to contain or clean up spills (absorbent pads, shovels, etc).
5. Make known to Drilling Supervisors a list of spill response contractors available.
6. BOP testing shall be performed each time a casing string is set.
7. The Drilling contractor is required to have a certified SPCC plan for the Drilling rig.
8. Routine inspections of the operations shall be performed to ensure SPCC guidelines are followed.
9. Ensure all Marathon personnel are HAZWOPER trained in methods for stopping, controlling, and cleaning up any spills.

Spill control measures to be taken:

1. Shut down activities underway, as deemed necessary by the person in charge.
2. Determine the source of pollution and stop the discharge, if possible.
3. Isolate and contain the discharged materials, if possible.
4. Seek guidance from the Southern Region Emergency Action Plan.