

# AQP Well Procedure

## CASING PROGRAM

Lease: ROBINIA DRAW UNIT NO. 2  
East Walker Draw Well No.: \_\_\_\_\_

Surface - Drill a 17 1/2" hole to 400'+ and set 13 3/8" casing.

Cement should be circulated to the surface.

AMOUNT	SIZE	PIPE REQUIREMENT WT./FT.	GRADE	CONNECTION
400'	13 3/8"	48.00	H-40	ST&C

## CASING EQUIPMENT & PREPARATION

Run casing with a guide shoe, 2 S-3 centralizers, 1 EZ-Lok clamp  
 and 2 lb. Halliburton Weld "A".

Position centralizer on bottom with EZ-Lok Clamp.

## CEMENT PROGRAM

Stage No.	Type & Additive Composition	Sl. WT. #/gal.	Sl. VOL. ft. <sup>3</sup> /sx.	Water gal./sx.	Pump Time	24 hr. Comp. St. psi @ degrees
400	Class C 2% CaCl	14.8	1.32	6.3		

Remarks: Use wood top plug to displace cement and leave 20 feet of cement  
 in the pipe, WOC +6 hours and nipple up. WOC 18 hours before drilling.