

11900-13200':

Drill Morrow section on air/mist carefully monitoring hole conditions while drilling. Log before loading hole with fluid. Load hole with low fluid loss (3 cc) brine gel/KCL polymer mud prior to running 4-1/2" liner.

**RECEIVED**

**JUL 26 1979**

**U.S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO**