

Florida Exploration Company
Ross Draw No. 10
Exhibit "F" Con't.

- (11) After cementing, the pressure will be released immediately. Then nipple up and install BOP's. Test casing to 5,000# for 30 minutes after WOC of 18 hours. Drill out after 24 hrs.
- (12) Drill 6½" hole to TD. Run same suite of logs.
- (13) Cement 5" or 4½" liner with 325 sacks class "H" plus 1.5% CF-9 plus .2% AF-11 plus 2% KCl.
- (14) Perforations, acid job, frac job or additional stimulation will be determined after completion.