

30-045-32437

CONOCOPHILLIPS CO

Page 1 of 3

Operations Summary Report

Legal Well Name: SAN JUAN 32-7 UNIT 214A
Common Well Name: SAN JUAN 32-7 UNIT 214A
Event Name: COMPLETION
Contractor Name:
Rig Name:

Start: 6/29/2004 Spud Date: 9/7/2004
Rig Release: End:
Rig Number: Group:

Date	From - To	Hours	Code	Sub Code	Phase	Description of Operations
9/14/2004	12:00 - 12:30	0.50	MOVE	MOB	DEMOB	SAFTY MEETING, RIG CREW & TRUCKING.
	12:30 - 14:00	1.50	MOVE	MOB	DEMOB	LOAD EQUIPMENT, MOVE TO NEW LOCATION.
	14:00 - 19:00	5.00	MOVE	RURD	MIRU	SPOT IN EQUIPMENT & RIG, START RIGGING UP
9/15/2004	07:00 - 07:30	0.50	SURFEQ	SFTY	MIRU	SAFTY MEETING.
	07:30 - 15:30	8.00	SURFEQ	RURD	MIRU	RIG UP EQUIPMENT, NIPPLE UP BOPS, RIG UP BLOOEIE LINES.
	15:30 - 16:30	1.00	WELLPR	PRTS	COMPZN	PRESSURE TEST CASING, 300 PSI FOR 10 MIN, 1800 PSI FOR 30 MIN, HELD
9/16/2004	16:30 - 19:00	2.50	RPEQPT	PULD	COMPZN	TALLY DP, & DCS, PICK UP & GO IN HOLE WITH 6 1/4" BIT, DCS & DP TO 3000' SHUT DOWN FOR NIGHT.
	07:00 - 07:30	0.50	WELLPR	SFTY	COMPZN	SAFTY MEETING.
	07:30 - 09:00	1.50	RPEQPT	PULD	COMPZN	FINISH PICKING UP DRILL PIPE.
	09:00 - 11:00	2.00	WELLPR	PRTS	COMPZN	PRESSURE TEST PIPE RAMS AS PER COPC REQUIRMENTS, HELD. RIG UP POWER SWIVEL.
	11:00 - 18:30	7.50	DRILL	DRLG	COMPZN	DRILL OUT CMT, FLOAT COLLAR, SHOE & OPEN HOLE, DRILL OUT OPEN HOLE WITH 800 CFM AIR/MIST, 6 BPH WATER, 1GAL FOAMER, 1/4 GAL INHIBITOR PER 10 BBLs, CIRCULATING PRESSURE 400 PSI. COAL INTERVALS AS FOLLOWS, 3336'-3340'=4', 3343'-3349'=6', 3359'-3367'=8', 3373'-3375'=3', 3391'-3407'=16', TOTAL COAL 37'.
	18:30 - 21:00	2.50	DRILL	CIRC	COMPZN	CIRCULATE HOLE CLEAN, CREW CHANGE, SAFTY MEETING.
	21:00 - 22:00	1.00	DRILL	CIRC	COMPZN	CUT WATER, DRY UP HOLE.
	22:00 - 22:30	0.50	RPEQPT	PULD	COMPZN	PULL BIT INTO 7" FOR FLOW TEST.
	22:30 - 23:30	1.00	FLOWT	PRDT	COMPZN	FLOW TEST, 15/MIN-15 PSI -PETO-3.75=1191 MCF, 30/MIN-15 PSI -PETO-3.75=1191 MCF 45/MIN-15 PSI -PETO-3.75=1191 MCF 60/MIN-15 PSI -PETO-3.75=1191 MCF
	23:30 - 00:30	1.00	EVALFM	SIPB	COMPZN	SHUT IN FOR PRESSURE BUILD UP, ISIP=35 PSI, 15/MIN=210 PSI, 30/MIN=290 PSI, 45/MIN=300 PSI, 60/MIN=300 PSI.
	00:30 - 02:00	1.50	RPEQPT	PULD	COMPZN	OPEN HCRS SURGE OFF PRESSURE, HANG BACK SWIVEL.
	02:00 - 05:00	3.00	RPEQPT	TRIP	COMPZN	POOH WITH DP, DCS & BIT
9/17/2004	05:00 - 06:00	1.00	WELLPR	RGSV	COMPZN	CHANGE OVER TO RUN UNDER REAMER.
	06:00 - 07:00	1.00	WELLPR	RURD	COMPZN	CHANGING OVER TO RUN UNDER REAMER
	07:00 - 07:30	0.50	WELLPR	SFTY	COMPZN	CREW CHANGE, SAFTY MEETING.
	07:30 - 10:00	2.50	RPEQPT	PULD	COMPZN	MAKE UP UNDER REAMER & SHOCK SUB, GO IN HOLE WITH DCS & DP TO 3314', RIG UP SWIVEL.
	10:00 - 16:00	6.00	DRILL	DRLG	COMPZN	UNDER REAM OPEN HOLE FROM 3314' TO 3517'
	16:00 - 17:00	1.00	DRILL	DRLG	COMPZN	CIRCULATE HOLE CLEAN
	17:00 - 18:00	1.00	DRILL	DRLG	COMPZN	CUT WATER, DRY UP HOLE.
	18:00 - 18:30	0.50	RPEQPT	PULD	COMPZN	PULL BIT INTO 7" FOR FLOW TEST.
	18:30 - 19:30	1.00	FLOWT	PRDT	COMPZN	FLOW TEST, 15/MIN-17 PSI-4.25 PETO=1270 MCF, 30/MIN-17 PSI-4.25 PETO=1270 MCF, 45/MIN-18 PSI-4.5 PETO=1304 MCF, 60/MIN-18 PSI-4.5 PETO=1304 MCF
	19:30 - 20:30	1.00	EVALFM	SIPB	COMPZN	SHUT IN FOR BUILD UP TEST, ISIP=40 PSI, 15/MIN=240 PSI, 30/MIN=285 PSI, 45/MIN=300 PSI, 60/MIN=300 PSI.
	20:30 - 00:00	3.50	RPEQPT	TRIP	COMPZN	OPEN HCR VALVES, SURGE OFF PRESSURE, POOH, LAY DOWN UNDER REAMER.
	00:00 - 02:30	2.50	RPEQPT	TRIP	COMPZN	MAKE UP 6 1/4" BIT ON DC, GO IN HOLE WITH BIT, DCS & DP, TAG, NO FILL.
	02:30 - 06:00	3.50	DRILL	CIRC	COMPZN	BLOW WELL AROUND, UNLOAD APPROX 1 BBL OF WATER, CIRCULATE HOLE CLEAN, PULL BIT INTO 7".
	06:00 - 07:00	1.00	RPEQPT	PULD	COMPZN	PULL BIT INTO 7"
	07:00 - 07:30	0.50	RPEQPT	SFTY	COMPZN	CREW CHANGE, SAFTY MEETING.
9/18/2004	07:30 - 10:00	2.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 290 PSI, RELEASE AS NATURAL SURGE.
	10:00 - 12:30	2.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=180 PSI, 30/MIN=265 PSI,

Operations Summary Report

Legal Well Name: SAN JUAN 32-7 UNIT 214A

Common Well Name: SAN JUAN 32-7 UNIT 214A

Event Name: COMPLETION

Contractor Name:

Rig Name:

Start: 6/29/2004

Rig Release:

Rig Number:

Spud Date: 9/7/2004

End:

Group:

Date	From - To	Hours	Code	Sub Code	Phase	Description of Operations
9/18/2004	10:00 - 12:30	2.50	STIMOP	STIM	COMPZN	45/MIN=270 PSI, 60/MIN=270 PSI, 75/MIN=275 PSI, 90/MIN=280 PSI, 105/MIN=280 PSI, 120/MIN=280 PSI, RELEASE AS NATURAL SURGE.
	12:30 - 15:00	2.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=195 PSI, 30/MIN=270 PSI, 45/MIN=275 PSI, 60/MIN=275 PSI, 75/MIN=280 PSI, 90/MIN=280 PSI, 105/MIN=280 PSI, 120/MIN=285 PSI, RELEASE AS NATURAL SURGE.
	15:00 - 17:30	2.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=195 PSI, 30/MIN=260 PSI, 45/MIN=270PSI, 60/MIN=270PSI, 75/MIN=275 PSI, 90/MIN=280 PSI, 105/MIN=280 PSI, 120/MIN=285 PSI, RELEASE AS NATURAL SURGE.
	17:30 - 20:00	2.50	RPEQPT	PULD	COMPZN	TIH FROM SHOE, TAG 5' FILL, BLOW WELL AROUND, CHECK FOR WATER, NO WATER, CIRCULATE HOLE CLEAN, PULL INTO 7" FOR FLOW TEST.
	20:00 - 21:00	1.00	FLOWT	PRDT	COMPZN	FLOW TEST, 15/MIN-20 PIS-5 PETO=1374 MCF, 30/MIN-22PSI,-5.5 PETO= 1454 MCF, 45/MIN-22PSI,-5.5 PETO= 1454 MCF, 60/MIN-23 PSI-5.75 PETO=1505 MCF.
	21:00 - 22:30	1.50	EVALWB	SIPB	COMPZN	SHUT IN FOR BUILD UP, ISIP=45 PSI, 15/MIN=200 PSI, 30/MIN=250 PSI, 45/MIN=290 PSI, 60/MIN=290 PSI. OPEN UP AS NATURAL SURGE.
	22:30 - 00:00	1.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=210 PSI, 30/MIN=270 PSI, 45/MIN=280 PSI, 60/MIN=290 PSI, RELEASE AS NATURAL SURGE.
	00:00 - 01:30	1.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=220 PSI, 30/MIN=270 PSI, 45/MIN=275PSI, 60/MIN=290 PSI, RELEASE AS NATURAL SURGE.
	01:30 - 03:00	1.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=220 PSI, 30/MIN=270 PSI, 45/MIN=290PSI, 60/MIN=300 PSI, RELEASE AS NATURAL SURGE.
	03:00 - 04:30	1.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=230 PSI, 30/MIN=285 PSI, 45/MIN=290PSI, 60/MIN=300 PSI, RELEASE AS NATURAL SURGE.
	04:30 - 06:00	1.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=230 PSI, 30/MIN=285 PSI, 45/MIN=290PSI, 60/MIN=300 PSI, RELEASE AS NATURAL SURGE.
	06:00 - 07:30	1.50	STIMOP	SFTY	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=240 PSI, 30/MIN=285 PSI, 45/MIN=295PSI, 60/MIN=300 PSI, RELEASE AS NATURAL SURGE. CREW CHANGE, SAFTY MEETING.
9/19/2004	07:30 - 09:00	1.50	STIMOP	STIM	COMPZN	SHUT IN FOR BUILD UP, 15/MIN=240 PSI, 30/MIN=285 PSI, 45/MIN=295PSI, 60/MIN=300 PSI, RELEASE AS NATURAL SURGE.
	09:00 - 11:00	2.00	RPEQPT	PULD	COMPZN	TIH FROM SHOE, CHECK FOR FILL, NO NEW FILL, BLOW WELL AROUND CHECK FOR WATER, NO WATER, CIRCULATE HOLE CLEAN.
	11:00 - 12:30	1.50	FLOWT	RURD	COMPZN	PULL BIT INTO 7" FLOW TEST, 15/MIN-20 PIS-5 PETO=1374 MCF, 30/MIN-22PSI,-5.5 PETO= 1454 MCF, 45/MIN-22PSI,-5.5 PETO= 1454 MCF, 60/MIN-22 PSI-5.5 PETO=1454 MCF.
	12:30 - 13:30	1.00	EVALFM	SIPB	COMPZN	SHUT IN FOR BUILD UP, ISIP=35 PSI, 15/MIN=205 PSI, 30/MIN=260 PSI, 45/MIN=270 PSI, 60/MIN=295 PSI.
	13:30 - 15:30	2.00	RPEQPT	PULD	COMPZN	RELEASE AS NATURAL SURGE, TIH FROM SHOE, NO NEW FILL, BLOW WELL AROUND, CLEAN OUT 5' FILL CIRCULATE HOLE CLEAN.
	15:30 - 19:00	3.50	RPEQPT	PULD	COMPZN	POOH LAYING DOWN DP & DCS, SECURE WELL FOR NIGHT.
9/20/2004	07:00 - 07:30	0.50	RPCOMP	SFTY	COMPZN	SAFTY MEETING, CHECK WELL PRESSURE, 300 PSI, BLEAD OFF PRESSURE WITH CHOKE MANIFOLD.
	07:30 - 08:30	1.00	RPCOMP	PULD	COMPZN	CHANGE OVER TO RUN PRODUCTION PIPE.
	08:30 - 11:00	2.50	RPCOMP	PULD	COMPZN	TALLY TBG, PICK UP TBG GO IN HOLE WITH RE ENTRY GUIDE, 2.25 F-NIPPLE WITH PLUG INSTALLED, 4 JTS 2 7/8" FL4S & 104 JTS 2 7/8" TBG, LAND TBG WITH F-NIPPLE AT 3404', EOT 3405'
	11:00 - 14:00	3.00	TREBOP	NUND	COMPZN	NIPPLE DOWN BOPS, NIPPLE UP WELL HEAD, TEST SEALS, HELD.
	14:00 - 16:00	2.00	RPEQPT	SLKL	COMPZN	RIG UP B & R, PULL PLUG IN F-NIPPLE, RIG DOWN B & R.

Operations Summary Report

Legal Well Name: SAN JUAN 32-7 UNIT 214A

Common Well Name: SAN JUAN 32-7 UNIT 214A

Event Name: COMPLETION

Contractor Name:

Rig Name:

Start: 6/29/2004

Rig Release:

Rig Number:

Spud Date: 9/7/2004

End:

Group:

Date	From - To	Hours	Code	Sub Code	Phase	Description of Operations
9/20/2004	16:00 - 19:00	3.00	MOVE	RURD	COMPZN	START RIGGING DOWN.
9/21/2004	07:00 - 07:30	0.50	MOVE	SFTY	DEMOB	SAFETY MEETING.
	07:30 - 19:00	11.50	MOVE	RURD	DEMOB	RIG DOWN EQUIPMENT, RIG DOWN RIG, GET READY FOR RIG MOVE.