

Preliminary OCD Plugging Procedure
New Mexico State #1 *
NE/4NW/4 Sec. 16, T30N, R16W
San Juan County, New Mexico

- (1) Pull rods and pump
- (2) Swab oil to Tank No. 7769
- (3) Plug as follows:
 - (a) 1109' up to 1004' w/ 50% excess
 - (b) WOC and then tag
 - (c) 714' up to 614' w/ 50% excess
 - (d) WOC and then tag
 - (e) 182' to surface
- (4) Abandon with erection of a steel marker showing High Plains Pet. as operator, New Mexico State #1, Unit Letter C, Sec. 16, T30N, R16N

* A wellbore diagram accompanies this procedure.