UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

RECEIVED

SEP 29 2011

Sundry Notices and Reports on Wells	E	Farmington Field Office Bureau of Land Managemen
	5.	Lease Number
1 The CANAL III		SF-079148
1. Type of Well	6.	If Indian, All. or
GAS GAS		Tribe Name
	7.	Unit Agreement Name
2. Name of Operator	3	
	=	
Conoco Phillips	な	
/옵,	& 8.	Well Name & Number
3. Address & Phone No. of Operator PO Box 4289, Farmington, NM 87499 (505) 326-9700	0.	San Juan 32 Fed Com 7
51502ei 81 17 34		
PO Box 4289, Farmington, NM 87499 (505) 326-9700	9.	API Well No.
4. Location of Well, Footage, Sec., T, R, M		30-045-29585
4. Location of Well, Footage, Sec., T, R, M	10.	Field and Pool
Unit K (NESW), 1509' FSL & 1522' FWL, Section 7, T32N, R9W, NMPM	10.	Basin Fruitland Coal
2 m 2 m 1 m 2 m 2 m 2 m 2 m 2 m 2 m 2 m		Dadin I raillana Cour
	11.	County and State
12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPO		San Juan, NM
12. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORTATION Type of Action Type of Submission Type of Action X Notice of Intent Abandonment Change of Plans Recompletion New Construction New Construction Plugging Non-Routine Fra Casing Repair Water Shut off Altering Casing Conversion to In	ORT, OTHER X on acturing	San Juan, NM
Type of Submission Type of Action X Notice of Intent Abandonment Change of Plans Recompletion New Construction Subsequent Report Plugging Non-Routine Frame Casing Repair Water Shut off	ORT, OTHER X on acturing	San Juan, NM DATA
Type of Submission X Notice of Intent Abandonment Recompletion Subsequent Report Plugging Non-Routine Fra Casing Repair Water Shut off Altering Casing Conversion to In	DRT, OTHER X on acturing jection	San Juan, NM DATA Other - Pull Liner & Clean out
Type of Submission X Notice of Intent Abandonment Recompletion Subsequent Report Plugging Casing Repair Water Shut off Conversion to In 13. Describe Proposed or Completed Operations ConocoPhillips Company requests permission to pull the production liner for the subject and current wellbore schematic.	DRT, OTHER X on acturing jection t well and clean	DATA Other - Pull Liner & Clean out
Type of Submission X Notice of Intent Abandonment Recompletion Subsequent Report Plugging Casing Repair Altering Casing Conversion to In ConocoPhillips Company requests permission to pull the production liner for the subject and current wellbore schematic. Type of Action Abandonment Recompletion New Construction New Cons	DRT, OTHER X on acturing jection	DATA Other - Pull Liner & Clean out
Type of Submission X Notice of Intent Abandonment Recompletion New Construction New Construction Non-Routine Fra Casing Repair Water Shut off Conversion to In 13. Describe Proposed or Completed Operations ConocoPhillips Company requests permission to pull the production liner for the subject and current wellbore schematic. 14. I hereby certify that the foregoing is true and correct. Signed Crystal Tafoya Title Staff (This space for Federal or State Office use)	DRT, OTHER X on acturing jection t well and clean	San Juan, NM DATA Other — Pull Liner & Clean out nout per the attached procedure echnician Date 9/28///
Type of Submission X Notice of Intent Abandonment Recompletion Subsequent Report Plugging Casing Repair Water Shut off Conversion to In 13. Describe Proposed or Completed Operations ConocoPhillips Company requests permission to pull the production liner for the subject and current wellbore schematic.	DRT, OTHER X on acturing jection t well and clean	San Juan, NM DATA Other - Pull Liner & Clean out nout per the attached procedu echnician Date 9/28///

p

ConocoPhillips SAN JUAN 32 FEDERAL COM 7 1

Lat 36° 59' 45.276" N

Long 107° 49' 14.124" W

PROCEDURE

- 1. Hold pre-job safety meeting. Comply with all COGCC, BLM, and COPC safety and environmental regulations. Test rig anchors prior to moving in rig.
- 2. MIRU work over rig. Check casing, tubing, and bradenhead pressures and record them in Wellview.
- 3. RU blow lines from casing valves and begin blowing down casing pressure. Kill well with produced Fruitland coal water, if necessary.
- 4. TOOH with pump and rods (See Pertinent Data Sheet. Only rods are in the well no pump assembly)
- 5. ND wellhead and NU BOPE. Rig up blooie line to flow back tank. Pressure test BOP equipment.
- 6. Unseat tubing hanger, check and note weight. Attempt to free tubing from 5 ½" liner, make up power swivel and rotate down to break up coal, if successful trip out of the hole with tubing.
- 7. If unable to dislodge 5 $\frac{1}{2}$ " casing, RU wireline specialties, RIH and chemical cut the 2 7/8" tubing above the F-nipple. If tubing is free TOOH, if not make another cut 1 joint up. TOOH and stand back tubing.
- 8. Make up 4 ¾" spear, 12- 4 ¾" drill collars with bumper sub, pick up and RIH with 2 7/8" AOH drill pipe. Engage spear in 5 ½" liner, trip out of the hole and stand back drill pipe and collars and lay down 5 ½" liner. (Note: use approved dispensation kill method for well control, see attached kill method.)
- 9. MU 6 1/4" bit, TIH and clean out fill to PBTD, circulate hole clean and trip into 7" casing.
- 10. RIH check fill, clean out as necessary. Trip out of the hole with bit.
- 11. Make up 6 ¼" X 9 ½" undereamer. TIH to 10' below the 7" casing shoe. Inject air and walk pressure up to 300 psi, drill slowly 5' to open hydraulic arms. Increase air and mist to a range of 1200 to 2000 scf/min and 10 to 12 bbls/hr mist. Underream open hole section to PBTD. Trip out of the hole and lay down undereamer.
- 12. Make up Baker 5-1/2" bladed shoe with float, six 5-1/2" 15.5# blank liner joints and a Baker Hyflo III liner hanger with cone slip grips on 2 7/8" workstring. Rotate to bottom if necessary, set hanger and release setting tool. TOOH and LD 2 7/8" AOH drill pipe and 4 ¾" drill collars. Immediately after recovering hanger setting tool, drop 2.25" ball in the well and close the blind rams. (Note: The ball will seat in the float allowing a column of fluid to be held in the liner.)
- 13. RU wireline. Pump 6 bbls. produced water to fill liner. Perforate using 3-1/8" HSC guns with 0.5" dia. holes @ 4 spf and 90 degree phasing. Perforate the following intervals <u>from the top down:</u> 3660-3670', 3673-3692', 3699-3703', 3819-3832' & 3837-3840'. See mudlog.
- 14. TIH with 2-7/8" tubing.

Recommended

Number	Description
1	2 7/8" Price Type cover joint (~30') 2 7/8" F nipple (1.78" ID)
1	2 7/8" F nipple (1.78" ID)
121	2 7/8" 6.5. J-55. EUE. 8rd tubing
As required for	2 7/8" 6.5, J-55, EUE, 8rd pup joints*
spacing	*Run 1 full joint above pups

15. ND BOP, NU B-1 adapter, rod radigan, and flow tee (place rod radigan below flow tee).

16. RIH with rods (detail below). Place 5 guides per rod where rod wear was found. Rod subs to be rotated each time the well is pulled to spread coupling wear in the tubing.

Number	Description	Pump Component Description
1	1.25" Insert Pump	Run RHAC-Z 2-1/2" x 1-1/4" x 10' x 14' Insert pump.
1	1" x 1' Lift Sub	Pump should have double standing and traveling
1	3/4" Guided Rod Sub	valves with California pattern ball and seats to comply
1	22K Norris Shear Tool	with new pump standards. Plunger to barrel clearance
6	1.25" Sinker Bars	to be .006 Do not set pump to tag.
147	3/4" Sucker Rods	• • •
As Needed	3/4" Pony Rods	
1	1.25" x 22' Polished Rod	

^{17.} Space out pump 1/2 inch for every 1000 ft of tubing depth and seat pump. Load tubing with water to pressure test tubing and pump to 1500 psi. Test for good pump action.

^{18.} Notify lease operator that well is ready to be returned to production. RD, MOL