Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals

Lease Serial No. NMNM0468128

abandoned well. Use form 3160-3 (A	6. If Indian, Allottee or Tribe Name		
SUBMIT IN TRIPLICATE - Other instructions on page 2		7. If Unit or CA/Agreement, Name and/or No. NMNM135234	
Type of Well Oil Well		8. Well Name and No. F-RPC 21 3	
2. Name of Operator Contact: PRISCILLA SHORTY HILCORP ENERGY COMPANY E-Mail: pshorty@hilcorp.com		9. API Well No. 30-045-31079-00-S1	
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	3b. Phone No. (include area code) Ph: 505.324.5188	10. Field and Pool or Exploratory Area WEST KUTZ PICTURED CLIFFS	
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish, State	
Sec 21 T29N R13W SWSW 762FSL 660FWL 36.707032 N Lat, 108.218359 W Lon		SAN JUAN COUNTY, NM	

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION				
☑ Notice of Intent ☐ Subsequent Report ☐ Final Abandonment Notice	☐ Acidize ☐ Alter Casing ☐ Casing Repair ☐ Change Plans ☐ Convert to Injection	☐ Deepen ☐ Hydraulic Fracturing ☐ New Construction ☐ Plug and Abandon ☐ Plug Back	☐ Production (Start/Resume) ☐ Reclamation ☐ Recomplete ☑ Temporarily Abandon ☐ Water Disposal	☐ Water Shut-Off ☐ Well Integrity ☐ Other	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.

Hilcorp Energy Company requests permission to temporarily abandon the subject well with the intent to return the well to production once gas prices rise. Please see the attached procedure and wellbore schematic.

NMOCD

SEP 05 2019

DISTRICT 111

14. I hereby certify that th	ne foregoing is true and correct. Electronic Submission #477336 verifie For HILCORP ENERGY COMP Committed to AFMSS for processing by	ANY, s	sent to the Farmington	
Name (Printed/Typed)	PRISCILLA SHORTY	Title	OPERATIONS REGULATORY TECH	
Signature	(Electronic Submission) THIS SPACE FOR FEDERA	Date	08/09/2019 STATE OFFICE USE	
Approved By JOE KIL		TitleE	NGINEER	Date 08/29/2019
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office Farmington erson knowingly and willfully to make to any department or agency of the United		

file 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.





Hilcorp Energy Company FRPC 21-3

Temporarily Abandon API #: 3004531079

PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1050', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 975', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

