Form 3160-5 (June 2015)

## UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY	5. Lease Serial No. NMNM101552						
Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.				6. If Indian, Allottee or Tribe Name			
SUBMIT IN	7. If Unit or CA/Agreement, Name and/or No.						
Type of Well	8. Well Name and No. WF FEDERAL 1 1						
Name of Operator HILCORP ENERGY COMPAN	9. API Well No. 30-045-30660-00-S1						
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	3b. Phone No. (include area code) Ph: 505-324-5188		10. Field and Pool or Exploratory Area HARPER HILL				
4. Location of Well (Footage, Sec., T	11. County or Parish, State						
Sec 1 T30N R14W NESW 194 36.841011 N Lat, 108.264197	SAN JUAN COUNTY, NM						
12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA							
TYPE OF SUBMISSION	TYPE OF ACTION						
<ul><li>☑ Notice of Intent</li><li>☐ Subsequent Report</li></ul>	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)		☐ Water Shut-Off		
	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation		☐ Well Integrity		
	□ Casing Repair	■ New Construction	☐ Recomplete		□ Other		
☐ Final Abandonment Notice	☐ Change Plans	□ Plug and Abandon	▼ Temporarily Abandon				
BP	☐ Convert to Injection	☐ Plug Back	□ Water Disposal				
13. Describe Proposed or Completed Opt If the proposal is to deepen directions Attach the Bond under which the wor following completion of the involved testing has been completed. Final Ab determined that the site is ready for fi Hilcorp Energy Company requ to return the well to production wellbore schematic.	ally or recomplete horizontally, will be performed or provide operations. If the operation respondent Notices must be file and inspection.	give subsurface locations and measur the Bond No. on file with BLM/BIA sults in a multiple completion or reco ed only after all requirements, includ- rarily abandon the subject we	red and true ver Required sub impletion in a n ing reclamation	rtical depths of all pertir sequent reports must be ew interval, a Form 316 I, have been completed a	nent markers and zones. filed within 30 days 0-4 must be filed once		

MMOCD

OCT n7 2019

DISTRICT 111

			5.0101 111	and developed			
14. I hereby certify that the foregoing is true and correct.  Electronic Submission #477514 verified by the BLM Well Information System  For HILCORP ENERGY COMPANY, sent to the Farmington  Committed to AFMSS for processing by JQHN HOFFMAN on 09/03/2019 (19JH0146SE)							
Name (Printed/Typed)	PRISCILLA SHORTY	Title	OPERATIONS REGULATORY TECH				
Signature	(Electronic Submission)	Date	08/12/2019				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved By JOHN HOFFMAN		TitleP	ETROLEUM ENGINEER	Date 09/03/2019			
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office	Farmington				
Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212 make it a crime for any person knowingly and willfully to make to any department or agency of the United							

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.



## Hilcorp Energy Company WF FEDERAL 1-1

Temporarily Abandon API #: 3004530660

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1550', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 1475', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tog to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

