

State of New Mexico Submit 3 Copies Form C-103 Energy, Minerals and Natural Resources Department to Appropriate Revised 1-1-89 District Office **OIL CONSERVATION DIVISION** DISTRICT I P.O. Box 2088 P.O. Box 1980, Hobbs, NM 88240 WELL API NO. Santa Fe, New Mexico 87504-2088 30-031-20489 DISTRICT II P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease X DISTRICT III 1000 Rio Brazos Rd., Aztec, NM 87410 State Oil & Gas Lease No SUNDRY NOTICES AND REPORTS ON WELLS 75 Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR VERMIT" (FORM C-101) FOR SUCH PROPOSALS.) SANTA FE PACIFIC RAILROAD 1. Type of Well WELL 8. Well No. 2 Name of Operato ROBERT L. BAYLESS 3. Address of Operator 9. Pool name or Wildcat P.O. BOX 168 FARMINGTON, NM 87499 Miguel Creek Gallup 4 Well Location 1750 Feet from the 990 **EAST** Η NORTH Feet from The Unit Letter 6W **McKINLEY** 16N Range NMPM County (Show whether DF, RKB, RT, GR, etc.) 10. Elevation Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PLUG AND ABANDON REMEDIAL WORK ALTERING CASING PERFORM REMEDIAL WORK CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT TEMPORARILY ABANDON PULL OR ALTER CASING CASING TEST AND CEMENT JOB OTHER: OTHER: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed 12. Describe Proposed or Completed Operations work) SEE RULE 1103. Robert L. Bayless plugged and abandon this well August 8, 2002. The procedure is attached. the best of my knowledge and belief. I hearby certify that the information above is TITLE ENGINEER 11/7/02 SIGNATURE (505) 327-2659 TELEPHONE NO. TYPE OR PRINT NAME DEPUTY OIL & GAS INSPECTOR, DIST. (2) (This space for State Use) APPROVED BY TITLE

1.25-03

CONDITIONS OF APPROVAL, IF ANY:

## Robert L. Bayless Plug and Abandon Report

SFPRR No. 21 1750' FNL & 990' FEL, Section 29, T16N, R6W McKinley County, NM

8/8/2002: Rig up JC Well Service. Trip out rods and pump. Trip out tubing. Pick up and trip in with 2 3/8" tubing. Tag PBD at 771'. Roll hole with water. Mix and spot 20 sack bottom plug at 770'. Trip out tubing.

8/8/2002: Trip in and tag plug at 583'. Casing held pressure. Perforate squeeze holes at 100'. Mix and pump 35 sacks cement. Cement did not circulate. Rigged down. Henry Villanueva with OCD was on location throughout job and approved cement volumes. Class B cement was used.

Installed abandonment marker and backfilled pit. Cleaned up location.