

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.  
**NM-13811**

6. If Indian, Allottee or Tribe Name  
**NA**

7. If Unit or CA, Agreement Designation

**NA**

8. Well Name and No.  
**Stevens No. 1**

9. API Well No.  
**30-045-24993**

10. Field and Pool, or Exploratory Area  
**Dakota**

11. County or Parish, State

**San Juan, NM**

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other **P&A**

2. Name of Operator

**WEXPRO COMPANY, c/o Celsius Energy Company**

3. Address and Telephone No.

**1331 17th Street, Suite 800, Denver, CO 80202 303-672-6914**

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

**790' FNL, 1520' FEL  
NWNE Section 29, T30N, R14W**

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent  
☒ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☒ Other **P&A**

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

The Stevens Well No. 1 was plugged and abandoned on 9/30/93 as follows:

1. Set 4-1/2" cement retainer at 5542'.
2. Spot 15 sx plug on top of retainer from 5542' to 5340'.
3. Spot 15 sx plug inside 4-1/2" casing from 4900' to 4698'.
4. Perforate squeeze holes at 2678'. Set retainer at 2629'.
5. Spot 10 sx cement on top of retainer from 2629' to 2494'.
6. Perforate squeeze holes at 1125'. Set retainer at 1061'.
7. Squeeze 50 sx cement below retainer and 8 sx on top. Plug inside casing 1125' to 950' outside casing 1125' to 891'.
8. Perforate squeeze holes at 847'. Set retainer at 774'.
9. Squeeze 45 sx below and 5 sx on top of retainer. Plug inside casing 847' to 706'; outside casing 847' to 642'.
10. Perforate at 580'. Pump 190 sx cement inside and outside casing from 580' to surface.
11. Cut off casinghead, cement dry hole marker, cut off anchors.
12. Location will be reclaimed to BLM specifications.

All plugging operations were witnessed by Kevin Schneider, Farmington BLM.

14. I hereby certify that the foregoing is true and correct

District Superintendent - West

October 5, 1993

Signed *[Signature]*

Title

Date

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title

APPROVED

OCT 19 1993

DISTRICT MANAGER

\*See Instruction on Reverse Side

FARMINGTON COPY

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

3WA-11/4/94

RECEIVED  
BLM  
53 OCT 18 AM 11:10  
070 FARMINGTON, NM  
MK-293-12/29/93