

well file

Gardner Bros

#1

Belknap - Santa Fe

13-19-6

Clean out to ≈ 280 or below 3048'
Cut and pull 5" as deep as possible

Cement Plug 3280 to 2850 w/ 75 sk
mud plug 2850 to 2000'

Cement Plug 2000 to 1850' w/ 25 sk

Cement plug from 50' in pipe stub w/ 25 sk
mud plug to 450'

Cement plug 450 to 350' w/ 25 sk

mud plug to 80'

Cement plug 80' to 60' w/ 10 sk

Set pipe marker 4" pipe 4' high

Clean and level location

TD 3438 or 3440

Ref 3352 - 60

3312 - 38

CI BP @ 3280

3038 - 48

3010 - 28

CI BP @ 2990

2952 - 62

2902 - 40

Packer on log @ 2880'

1912 - 30

Top MV 428

MANCOS 2900 $\pm$

GALLUP 3100 $\pm$

Plugging Program
5-4-62