

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

1. Type of Well
OIL

2. Name of Operator
Geo Engineering

3. Address & Phone No. of Operator
P.O.Box 2966
Santa Fe, NM 87505

4. Location of Well, Footage, Sec., T, R, M
Sec. 29, T-20-N, R-9-W, NMPM, McKinley County
Unit B, 1115' FNL and 2325' ~~FWL~~
FEL

API # (assigned by OCD)
30-031-05357

5. Lease Number
Fee

6. State Oil & Gas Lease #

7. Lease Name/Unit Name
Santa Fe Pacific I

8. Well No.
#22

9. Pool Name or Wildcat

10. Elevation:

Type of Submission

☐ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment

Type of Action

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other -

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut off

☐ Conversion to Injection

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, plugged and abandoned said well according to the attached Daily Report.

This work was completed under State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor
William F. Clark

March 4, 1998

(This space for State Use)

Approved by Johnny Robinson

DEPUTY OIL & GAS INSPECTOR, DIST. #3
Title _____

Date

MAR 13 1998

Daily Report

A - PLUS WELL SERVICE

P.O. BOX 1979 • FARMINGTON, NM 87499
505-325-2627 • FAX (505) 325-1211

Rig No 6-1Date 2/26/98Well No Santa Fe Pacific #22 Location Sec. 29 T20N R9W Company Geo Engineering

FROM	TO	DESCRIPTION OF OPERATION
<u>2/26/98</u>		
<u>2PM</u>	<u>3:30PM</u>	<u>Move Cement Equipment to Top of Hill & Loc.</u>
<u>3:30</u>	<u>3:45PM</u>	<u>Weld on 2" Colloc Run WL in Hole to 359' & Tag.</u>
<u>3:45</u>	<u>4PM</u>	<u>Pump down 2" CSG. Pressured up to 800 PSI Bleed down to 500 PSI Pump up to 1000 PSI Holding.</u>
<u>4PM</u>	<u>4:15</u>	<u>Run in Hole w/ 1-1 1/2" Biwire shot And Perf at 300'</u>
<u>4:15</u>		<u>Pump in to Perf at 300' at 100 PSI at 1 1/2 BPM Pump 6 BPM</u>
	<u>4:30</u>	<u>No circulation Behind CSG</u>
<u>4:30</u>	<u>4:45</u>	<u>Plug #1 Mix 16 SX cement Disp to 30' Shut well in w/ 100 PSI</u>
<u>4:45</u>		<u>Perf at 31' w/ 1-1 1/2" Biwire shot Pump 3 BPM in perf get Circulation Behind 2" CSG</u>
		<u>Plug #2 Mix 16 SX started getting cement Returns circulation</u>
		<u>Lost Circulation Top of cement was down Behind 2" CSG approx 2'</u>
	<u>6PM</u>	<u>Fill Backside w/ Cement shut well in WASH install mark.</u>

Fuel & Motor Oil _____ Water Hauled _____

Rental Equipment _____ Cement Retainers _____

Cementing Plug #1 16 SX Plug #2 16Wireline Perf 1 Hole at 300' w/ 1 1/2" Biwire shot Perf 1 Hole 31' w/ 1 1/2" Biwire