

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

<p>1. Type of Well OIL</p> <hr/> <p>2. Name of Operator Geo Engineering</p> <hr/> <p>3. Address & Phone No. of Operator P.O.Box 2966 Santa Fe, NM 87505</p> <hr/> <p>4. Location of Well, Footage, Sec., T, R, M Sec. 29 T-20-N, R-9-W, NMPM, McKinley County Unit A, 5' FNL and 1130' FEL</p>	<p>API # (assigned by OCD) 30-031-05385</p> <p>5. Lease Number Fee</p> <p>6. State Oil & Gas Lease #</p> <p>7. Lease Name/Unit Name Santa Fe Pacific I</p> <p>8. Well No. #8</p> <p>9. Pool Name or Wildcat</p> <p>10. Elevation:</p>
--	---

Type of Submission	Type of Action	
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other -	

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, will plug and abandon said well according to the attached procedure prepared by NMOCD.
This work will be in accordance with State of New Mexico Contract No. 98-521.25-059.

RECEIVED
JAN 22 1998
OIL CON. DIV.
DIST. 3

SIGNATURE William F. Clark Contractor
William F. Clark

December 30, 1997

(This space for State Use)

Approved by Johnny Robinson Title DEPUTY OIL & GAS INSPECTOR, DIST. #3 Date JAN 22 1998

COMPANY Geo Engineering		PROPERTY NAME Sante Fe Pacific I	WELL NO. 8
DATE	LOCATION (ULSTR) A-29-20N-09W	FOOTAGE	
API NO.	POOL		

2" thg. & Elbow with a 2" to 1" swedge

CASING RECORD:

2" csg. @ 450'
calc. T.O.C. @ 409'

1. Determine depth of well
2. If depth is 300' or more continue procedure. If not move a rig in & clean out to 300'
3. Perfs @ 300' + 30'. Est. circ. to the surf.
4. GIH with slickline & load csg. with cement
5. POH with slickline & pump cement down the csg. & circ. cement the surf.
6. Install dry Hole Marker

