## State of New Mexico Energy, Minerals and Natural Resources Department Oil Conservation Division

Sundry Notices and Reports on Wells					
1.	Type of Well OIL	2		<b>API</b> 5. 6.	# (assigned by OCD) 30-031-05343 Lease Number Fee State Oil & Gas Lease #
2.	Name of Operator Geo Engineering			7. 8.	Lease Name/Unit Name Santa Fe Pacific Well No.
3.	Address & Phone No. of Operator P. O. Box 2966 Santa Fe, NM 87505	)r		9.	#9 Pool Name or Wildcat
4.	Location of Well, Footage, Sec., Sec. 20 T-20-N, R-9-W, NMPM, Unit O, 110' FSL & 1910' FEL		_	10.	Elevation:
	Type of Submission  Notice of Intent  X Subsequent Report	Type of Action  X Abandonment Recompletion Plugging Back	Change of I New Const Non-Routir	ructio	
	Final Abandonment	Casing Repair Altering Casing Other -	Water Shu Conversion	t off	
13	A-Plus Well Service, contract attached Daily Report on Feb.	tor, plugged and abando oruary 11, 1998.			
SIG	GNATURE Milliam F. Clark	Contractor _	D	<u>ecem</u>	ber 30, 1997
(TI	proved by frame Course	OFFISTY CO. K. GAS DISPECT	ગાર છે. <b>કુંડે</b> Date _	FE	B 1 / 1998

Daily Report

## A - PLUS WELL SERVICE

13978

P.O. BOX 1979 • FARMINGTON, NM 87499

	•	505-325-2627 • FAX (505) 325-1211
Rig No _	7	505-325-2627 • FAX (505) 325-1211  Date 2/4/43 - 2/1/48
Well No_	SFP#	9 Location RED m TW Company
FROM	то	DESCRIPTION OF OPERATION
2-6-	98	
1/:00	11:30	Run wh in to 428 + tag cut off at wellhead
2/10	1/98	
12NON	1PM	move to Well Rigup Rig to & Pump T
1Pm	2PM	Move to Well Rigur Rig #7 & Pump T Run in Hole W/ 421 of 12 Tubing. Try.
		Pump 2 BBL Water got circulation
2Pm		Plug 1 Mix 40 SX coment at 15.4th + spot from 42 to
		Pump 2 BBL water got circulation  Plug # 1 Mix 40 SX coment at 15.4# + spot from 421 +0  Surface Pull Tubring up to 30. Then Circulate well clean!
	3PM	WASL & MOVE off to SFP#36
2/11/	98	
900	10Am	Weldon Csy collar
, 1741S	107,6	<del></del>
10:30		move to Well Rigup WL & PT Run in Hole Tag Plug #1
	10:45	move to Well Rigup WL & PT Run in Hole Tag Plug#1 AT 25 Perf 2-28 Biwire shot at 25
10:45	11 Am	Pump 4BBL wrote in to And At 100 PSI No circulations
		Behing CSS to Surface.
IIAm		Plug#2 mix 12 5x Pump chown Csg. No circulation/
		Shut Well IN W/50PSI Bleed down 4 Set Marken
		move off to SFP#2

Fuel & Mo	tor Oil	Wat	er Hauled		
Dontal Ear	inmont	Com	Coment Retainare		

Cementing Plug#1 405x Plug#2
Wireline 2- 24 Biwice shot at 25