

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division

Sundry Notices and Reports on Wells

1. Type of Well OIL	API # (assigned by OCD) 30-031-20062
	5. Lease Number Fee
	6. State Oil & Gas Lease #
2. Name of Operator Geo Engineering	7. Lease Name/Unit Name Santa Fe Pacific
	8. Well No. #102
3. Address & Phone No. of Operator P.O.Box 2966 Santa Fe, NM 87505	9. Pool Name or Wildcat
4. Location of Well, Footage, Sec., T, R, M Sec. 21 T-20-N, R-9-W, NMPM, McKinley County Unit P, 565' FSL and 165' FEL	10. Elevation:

Type of Submission

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment

Type of Action

☒ Abandonment	☐ Change of Plans
☐ Recompletion	☐ New Construction
☐ Plugging Back	☐ Non-Routine Fracturing
☐ Casing Repair	☐ Water Shut off
☐ Altering Casing	☐ Conversion to Injection
☐ Other -	

13. Describe Proposed or Completed Operations

A-Plus Well Service, contractor, will plug and abandon said well according to the attached procedure prepared by NMOCD.

This work will be in accordance with State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor

December 30, 1997

RECEIVED
JAN 22 1998
OIL CON. DIV.
DIST. 3

(This space for State Use)

Approved by Johnny Robinson DEPUTY OIL & GAS INSPECTOR, DIST. #3

Date JAN 22 1998

COMPANY

Geo Engineering

PROPERTY NAME

Santa Fe Pacific

WELL NO.

102

DATE

7-31-99

LOCATION (ULSTR)

P-21-20N-09W

FOOTAGE

API NO.

POOL

5 1/2 csg threaded with
plastic cap. Above ground 1 ft.

CASING RECORD:

5 1/2 csg. (no collar) 310'
cement 174' calc.

PTA Procedure

Rigless

cement from
TD to Surf

174'

T.O.C
calc255XS.
5 1/2

310'

O.H
340'

COMPANY Geo Engineering		PROPERTY NAME Santa Fe Pacific		WELL NO. 102
DATE 7-31-91	LOCATION (ULBOR) P-21-20N-09W		FOOTAGE	
API NO.		POOL		

5 1/2 csg threaded with
plastic cap. Above ground 1 ft.

CASING RECORD:

5 1/2 csg. (no collar) 310'
cement 174' calc.

P+A Procedure

1. G1H + determine depth
2. If depth is 300' or more continue with procedure if not move rig in + clean out csg to 300'
3. Perf. @ 30' establish circ. to surf.
4. G1H with slick lined load hole with cement
5. PCH with slick line + pump cement down the csg. + circ. cement to the surf.
6. Install dry hole marker

