

PICK UP WORK STRING
SPOT 250' CEMENT PLUG ACROSS PERFORATIONS () INSIDE CASING
WAIT ON CEMENT AND TAG, PRESSURE TEST CASING
SET SURFACE PLUG CEMENT 250'
INSTALL P&A MARKER
CLOSE PITS ACCORDING TO NMOCD GUIDELINES
CLEAN AND LEVEL LOCATION