

RECEIVED

NOV 26 1984

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☒ gas well ☐ other ☐
2. NAME OF OPERATOR
Cities Service Company
3. ADDRESS OF OPERATOR
Box 1919, Midland, Texas 79702
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 330' FNL & 1650' FEL
AT TOP PROD. INTERVAL: Same as above
AT TOTAL DEPTH: Same as above
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

- TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☐
(other) ☐

SUBSEQUENT REPORT OF:

- ☐
☐
☐
☐
☐
☐
☐
☐
☐
☒

RECEIVED

NOV 01 1982

U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

OTD 5460' Sandstone, OPBTD 5438'. This well was plugged and abandoned in the following manner:

1. MIRU pulling unit. POOH w/rods. NU BOP. Pulled 2-7/8" tbg. Circ hole w/mud laden fluid.
2. RU wireline. Ran gauge ring and junk basket to 5150'. POOH. Set CIBP on WL @ 5125'. Dumped 5 sacks cement on top of CIBP. RD WL.
3. RIH w/OE tbg. to 4200'. Circ hole w/9.2 #1 gal mud. Spotted 12 sack cement plug 4200 - 4100' (across the top of the Dakota zone).
4. POOH w/tbg to 3050'. Spotted 25 sack cement plug 3050-2850' across top of the Gallup zone.
5. POOH to 550'. Spotted 12 sack cement plug 550 - 450'.

Subsurface Safety Valve: Manu. and Type _____

Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

David C. Zimmerman

TITLE

Reg. Pet. Eng.

DATE

October 28, 1982

(This space for Federal or State office use)

TITLE

DATE

OCT 28 1982

NMOCC

M. MILLENBACH
AREA MANAGER

Approved as to plugging of the well bore.
Liability under bond is retained until surface restoration is completed.

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

GPO : 1976 O - 214-149

6. POOH to 255'. Spotted 12 sack cement plug 255 - 155' half above and half below 8-5/8" casing shoe @ 205'.
7. POOH w/tbg. CO WH. Spotted 6 sack cement plug 50' to surface.
8. Install 4" dry hole marker 4' above and 6' below ground level to designate a plugged and abandoned location.

Geological Survey was notified but did not witness.