Submit 3 Copi
to Appropriate
District Office
DISTRICT I
P.O. Box 1980

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

JUN 102002

OIL CONSERVATION DIVISION WELL API NO. P.O. Box 2088 0, **k**obbs, NM 88240 30-031-20624 Santa Fe, New Mexico 87504-2088 DISTRICT II 5. Indicate Type of Lease P.O. Drawer DD Artesia, NM 88210 X FEE STATE DISTRICT III 6. State Oil & Gas Lease No. 1000 Rio Brazos Rd., Aztec, NM 87410 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" SANTA FE PACIFIC RAILROAD (FORM C-101) FOR SUCH PROPOSALS.) I. Type of W OIL WELL 8. Well No. 2. Name of Op 29 ROBERT L. BAYLESS 9. Pool name or Wildcat 3. Address of perator P.O. BOX 168 FARMINGTON, NM 87499 Miguel Creek Gallup 4. Well Local 330 SOUTH Feet from The 1650 Feet from the Unit Le 6W 16N NMPM 20 Township Range Section 10. Elevation (Show whether DF, RKB, RT, GR, etc.) Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. SUBSEQUENT REPORT OF: NOTICE OF INTENTION TO: ALTERING CASING REMEDIAL WORK PLUG AND ABANDON PERFORM REMEDIAL WORK COMMENCE DRILLING OPNS PLUG AND ABANDONMENT CHANGE PLANS TEMPORARILY ABANDON CASING TEST AND CEMENT JOB PULL OR ALTER CASING OTHER: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed Proposed or Completed Operations 12. Describ SEE RULE 1103. work) Robert L. Bayless intends to plug and abandon this well by June 1, 2003. The procedure is attached. y knowledge and belief. I hearby certify that the information above is true and complete to 6/6/02 **ENGINEER** TITLE SIGNATURE (505) 327-2659 TELEPHONE NO. Tom McCarthy TYPE OR PRINT NAME L & EAS INSPICTOR, MAI. 20

CONDITIONS OF APPROVAL, IF ANY:

(This space fo APPROVED BY

Robert L. Bayless Plug and Abandon Procedure

SFPRR No. 29 1650' FSL & 330' FEL, Section 20, T16N, R6W McKinley County, NM

Well data:

Surface Casing: None.

Production Casing: 4.5" 10.5# casing set at 786'. Cemented with 160 sxs.

TD: 797' PBD: 797'

Perfs: 786-97'OH. Tubing: 2 3/8" 804'.

Rods: 797'.

- 1. Install rig anchors if necessary. Dig small workover pit if necessary.
- 2. Move in rig.
- 3. If well has rods, unseat pump and move rods to see if they are free. Reseat pump and pressure test tubing to 1000 PSI. Trip out laying down rods and pump.
- 4. Pick up extra tubing and tag PBD. Trip out and tally tubing. Inspect tubing. Pick up work string if necessary.
- 5. Trip in with tubing open ended. Tag PBD and raise tubing 2'. Circulate casing clean. Spot balanced Cement Plug No. 1 (see volume below) down tubing. Trip out above cement and WOC. Trip in and tag cement. Spot additional plug if necessary.
- 6. Trip out with tubing.
- 7. Rig up wireline. Perforate 3 squeeze holes at 100°. Attempt to establish circulation out the bradenhead (if there is one) or outside the production string to the surface. Mix cement for **Cement Plug No. 2** (see volume below) and pump down casing, attempting to circulate to surface. Shut in and WOC.
- 8. Cut off casing. Fill casings with cement if necessary. Install P & A marker. Rig down and move off.

Cement Plug No. 1: 13 sx. Cement Plug No. 2: 45 sx.

Notes: All cement will be Class B Neat.

Other than the cement, the well bore fluid will be 8.3 PPG water.

All cement volumes will be 100% excess outside casing and 50' excess inside casing.