

GOVERNOR

#### STATE OF NEW MEXICO

## ENERGY AND MINERALS DEPARTMENT

# OIL CONSERVATION DIVISION AZTEC DISTRICT OFFICE

1000 RIO BRAZOS ROAD AZTEC, NEW MEXICO 87410 (505) 334-6178

### Division Approved Plugging Program

Gerald J. Prom
Crownpoint #1 F-18-18N-13W

### Downhole Equipment

- 8 5/8" at 83' W/35 sx. cir.
- 5 1/2" at 1470' W/175 sx. circ.
- 4 3/4" at open hole 1470-1560
- 1. Clean out hole to TD (1560')
- 2. Set a cement plug 1560'-1350'
- 3. WOC a minimum of 4 hours. Go in hole with tubing and tag bottom plug. If plug is above 1400' go to step 4. If not, fill to 1350'.
- 4. Set a cement plug 550'-450' inside casing.
- 5. Set a cement plug 130' to surface inside casing.
- 6. Set marker fill pits, clean and level location.

All plugs will be with Class A, B or C cement with or without an accelerator.

