

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		6. IF INDIAN, ALLOTTEE OR TRIBE NAME 09-159 Jicarilla Cont. 159
2. NAME OF OPERATOR SHERMAN F. WAGENSELLER		7. UNIT AGREEMENT NAME
3. ADDRESS OF OPERATOR %M.B. Jones, 1223 Bank of New Mex. Bldg., Albuq, NM 87102		8. FARM OR LEASE NAME Mobil Apache
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1850 fsl & 790 fwl		9. WELL NO. 5
14. PERMIT NO.		10. FIELD AND POOL, OR WILDCAT South Blanco PC
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 7231 DF, 7225 GR		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 7-23N-2W-NMP
		12. COUNTY OR PARISH Rio Arriba
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☒
(Other)

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☐
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other)

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Hole in 4 1/2" casing as determined by bradenhead pressure test.

Plan to move on workover rig and set bridge plug above Pictured Cliffs perms(3016 - 3028). Locate casing hole with packer. Squeeze with sufficient Class B cement with 3% CaCl₂ to repair leak. Drill out cement and pressure test casing, if OK, will drill out bridge plug, rerun tubing and put well on production.

No new surface disturbance required for this repair.



18. I hereby certify that the foregoing is true and correct

SIGNED MORRIS B. JONES

TITLE Morris B. Jones, Engineer

DATE April 10, 1978

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____

*See Instructions on Reverse Side

clerk

55