

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT - " for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

ENERGEN RESOURCES CORPORATION

3. Address and Telephone No.

2198 Bloomfield Highway, Farmington, NM 87401

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

990' FNL, 1650' FWL, Sec. 22, T23N, R3W, N.M.P.M.

5. Lease Designation and Serial No.

Jicarilla Contract 413

6. If Indian, Allottee or Tribe Name

Jicarilla Apache

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Chacon Jicarilla D 4

9. API Well No.

30-039-20206

10. Field and Pool, or exploratory Area

W Lindrith Gallup Dakota

11. County or Parish, State

Sandoval NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☒ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is intended to repair a casing leak in this well as follows:

1. MIRU. TOH
2. TIH with packer and RBP. Test casing and isolate leak.
3. Squeeze cement with sufficient amount of cement to repair leak. WOC.
4. TIH with bit and drill out squeeze. Test casing to 500 psi. TOH
5. TIH and clean out to PBTD. Land tubing and return well to production.



14. I hereby certify that the foregoing is true and correct

Signed Heidi Donaghy

Title Production Assistant

Date 10/9/00

(This space for Federal or State office use)

Approved by /s/ Brian W. Davis

Title Lands and Mineral Resources

Date OCT 18 2000

Conditions of approval, if any: