

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
30-043-20330

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
Helton Engineering & Geological Services, Inc.	Diamond Trail Ranch
3. Address of Operator	9. Well No.
860 Anaconda Tower, 555-17th Street, Denver, Colorado 80202	Brent No. 1
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER M, 80 FEET FROM THE west LINE AND 1100 FEET FROM	Wildcat
THE south LINE, SECTION 29 TOWNSHIP 13N RANGE 6E NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
5936 GL	Sandoval

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well was plugged and abandoned on 8/9/79 as follows:

1. Tagged top of plug at 1575.
2. Set 20 sack plug from 1600 to 1540 ft.
3. Set 65 sack plug from 550 ft. to 350 ft.
4. Set 15 sack plug from 170 to 130 ft.
5. Set 5 sack plug on top of surface pipe.
6. Set dry hole marker.
7. Cleaned and leveled location.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jerome B. Weber</u>	TITLE _____	DATE <u>8/30/79</u>
APPROVED BY <u>AR Hendrick</u>	TITLE _____	DATE <u>SEP 4 1979</u>
CONDITIONS OF APPROVAL, IF ANY:		