

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN REPLICATED
(Other instructions on reverse side)

Form approved
Budget Bureau No. 42-R143

2. LEASE DESIGNATION AND SERIAL NO.
NM-16586

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different formation.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

BCO, Inc.

3. ADDRESS OF OPERATOR

P. O. Box 669 Santa Fe, New Mexico 87504

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1850' FSL and 990' FEL Sec. 33 T23N R7W

14. PERMIT NO.

15. ELEVATIONS (Show whether OF, AT, OR, etc.)

6866' GR

6. IF INDIAN, ALIQUOT OR TRIBAL NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Federal I

9. WELL NO.

2

10. FIELD AND FORM. OF WILDCAT
Undesignated Gallup

11. SEC., T., R., OR BLK. AND
SURVEY OR AREA

Sec 33 T23N R7W

12. COUNTY OR PARISH 13. STATE
Sandoval NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT ON:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well.
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Believe well has casing failure. Intend to set RBP above Gallup perms (4894-5108) and then use a packer to find the hole in the casing. Intend to repair said hole with cement, let cement set for at least 48 hours, then drill out cement, remove RBP, swab well and place back in production.

A small pit will be dug on the well pad if the well has a casing failure and fenced. It will be covered up in the spring.

The above work is anticipated to start on November 28, 1983 and was verbally approved by Ken Townsend with the Bureau of Land Management on November 23, 1983.

RECEIVED

NOV 29 1983

BLM DIV.

18. I hereby certify that the foregoing is true and correct

SIGNED

Harry R. B...

TITLE

President

DATE 11/23/83

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

NMOCC

DATE

R. B...