

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-11928

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

BOC

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

WILDCAT

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10, T22N, R1W

12. COUNTY OR PARISH 13. STATE

Sandoval

New Mex.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ P & A Junk Hole

2. NAME OF OPERATOR

Coleman Oil & Gas, Inc.

3. ADDRESS OF OPERATOR

6109 Del Campo Pl. N.E.

Albuquerque, New Mexico 87109

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1570'FSL, 810'FWL

JUN 28 1981

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

TON, N. M.

7677 Gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

X

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

TD 2395, Plug & Abandon

6-4-81 Re-entered hole. Spot cement plug over
perfs 2230-34, 2244-48, 2264-70, 2318-24 with 55 sx. WOC.

6-10-81 Drilled out cement, twist off locked up bit in casing shoe.

6-15-81 Spot 500' cement plug 1880-2380 - 40 sacks.
Shot 4 sqz holes @ 200, pumped into back side and placed
surface plug 0-200' with 62 sacks.

Install dry hole marker - Job Comp. 7 PM, 6-15-1981.

18. I hereby certify that the above is true and correct

SIGNED

TITLE Agent

DATE 6-24-1981

(This space for Federal or State official)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

NMOCC

*See Instructions on Reverse Side

Stan McKee