

Cementing attachment for 7" casing.

Lewis 22-21-2 #1

Casing Shoe set @ 4793'. DV Tool set @ 3285'.

First Stage: Lead cement 80 sx 50/50 poz + 6% gel  
Tail cement 150 sx class "B"

Second Stage: 450 sx 50/50 poz + 6% gel. Cement  
was circulated.

