Form 9-331 (May 1963)

16.

UNITED STATES SUBMIT IN TRIPLICATE® Other instructions on reverse side)

Form approved. Budget Bureau No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

NM 8904

San Juan.

| GEOLOGICAL SURVEY | | | | | | | |
|-------------------|---------|-----|---------|----|-------|--|--|
| SUNDRY | NOTICES | AND | REPORTS | ON | WELLS | | |

6707 GR

| 14. | PERMIT NO. | 15. ELEVATIONS (Show whether DF, RT, GR, etc.) | 12. COUNTY OR PARISH | 13. STATE |
|-----|---|--|---|-----------|
| | | | Sec 5, T22N | |
| | 990' FNL and | 1650' FEL | 11. SEC., T., R., M., OR BI SURVEY OR AREA | LK. AND |
| | See also space 17 below.) At surface | | Wildcat | |
| 4. | LOCATION OF WELL (Report location clear | ly and in accordance with any State requirements. | 10. FIELD AND POOL, OR | WILDCAT |
| | 4949 San Pedro | N.E., Suite #47, Albuquerque,NM | 1 | |
| 3. | ADDRESS OF OPERATOR | | 9. WELL NO. | |
| | C. C. Kennedy | | Beard | |
| 2. | NAME OF OPERATOR | | 8. FARM OR LEASE NAM | E |
| | OIL GAS WELL Y OTHER | | | |
| 1. | | | 7. UNIT AGREEMENT NAM | of IC |
| | (Do not use this form for proposals | to drill or to deepen or)lug back to a different reservoir. ON FOR PERMIT—" for such proposals.) | | |

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

| NOTICE OF INTENTION TO: | | | | 1 | SUBSEQUENT REPORT OF: | | | Ψ. |
|---|--|--|----------|---|--|------------------|--|----|
| TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) | | PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON* CHANGE PLANS | <u>X</u> | | WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING (Other) | ults of multiple | REPAIRING WELL ALTERING CASING ABANDONMENT* completion on Welt and Log form.) | |
| · | | <u> </u> | | | | | | |

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well will be plugged and abandoned as follows:

- Squeeze perforations 1331 1644 and leave cement plug 1. from 1200 to 1640.
- Squeeze perforations 912-918 and leave cement plug from 2. 800 to 918.
- Set cement plug from 350 to 500 feet. 3.
- Set cement plug from C to 50 feet.
- Install dry hole marker and clean up location.



| | Oi- Dia | | |
|---|-------------|--------|---------|
| SIGNED William T. Jones | TITLE Agent | DATE _ | 12-9-76 |
| (This space for Federal or State office use) APPROVED BY CONDITIONS OF APPROVAL, IF ANY: | TITLE | DATE _ | |