

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	5. LEASE DESIGNATION AND SERIAL NO. NM 8904
2. NAME OF OPERATOR C. C. Kennedy	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR 4949 San Pedro N.E., Suite 47, Albuquerque, N.M.	7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990' FNL and 1650' FEL	8. FARM OR LEASE NAME Beard
14. PERMIT NO.	9. WELL NO. 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6707 GR	10. FIELD AND POOL, OR WILDCAT Wildcat
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 5, T22N, R8W
	12. COUNTY OR PARISH San Juan
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well was plugged and abandoned as follows:

1. Squeezed perforations 1331 - 1644 and left cement plug from 1200 to 1644.
2. Squeezed perforation 912-913 and left cement plug from 800 to 920.
3. Set cement plug from 350-500 feet.
4. Set cement plug from 0 to 50 feet.
5. Cut off Bradenhead, welded on plate and installed dry hole marker.

Well officially P & A at 2:00 p.m. on 12-9-76.



DEC 13 1976

18. I hereby certify that the foregoing is true and correct

SIGNED

William T. Jones
William T. Jones

TITLE

Agent

DATE

12-9-76

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE