lerie 9-351 (May 1963)

N.A

At surface

3. AD

16.

## UNITED STATES SUBMIT IN TRIPLICATE\* DEPARTMENT OF THE INTERIOR (Other instructions on reverse side)

Form approved. Budget Bureau No. 42-R1424. 5. LEASE DESIGNATION AND SERIAL NO.

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

GEOLOGICAL SURVEY

	~~~/
N 1 N 1	Onn
NM	A4114
1111	8904

	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or p ug back to a different reservoir.  Use "APPLICATION FOR PERMIT—" for such proposals.)	
	7. UNIT AGREEMENT NAME
OIL GAS X OTHER	* + + + + + + + + + + + + + + + + + + +
	8. FARM OR LEASE NAME
NAME OF OPERATOR	Beard
C. C. Kennedy	9. WELL NO.
4949 San Pedro N.E., Suite 47, Albuquerque, N.M.	1 = 5 1 2 2
LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*	10. FIELD AND POOL, OR WILDCAT
LOCATION OF WELL (REPORT REALITY AND IN ACCOUNTS AND IN ACCOUN	Wildoot
At surface	Wildcat

990' FNL and 1650' FEL Sec 5, T22N, R8W 12. COUNTY OR PARISH 13. STATE 15. ELEVATIONS (Show whether DF, RT, GR, etc.) 14. PERMIT NO.

San Juan <u>New Mexico</u> 6707 GR

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:	
FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL  (Other)  PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON* CHANGE PLANS	WATER SHUT-OFF  FRACTURE TREATMENT SHOOTING OR ACIDIZING  (Other)  (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Well was plugged and abandoned as follows:

- Squeezed perforations 1331 1644 and left cement plug from 1200 to 1644.
- Squeezed perforation 912-918 and left cement plug from 800 to 920.
- Set cement plug from 350-500 feet.
- Set cement plug from 0 to 50 feet.
- Cut off Bradenhead, welded on plate and installed dry hole marker.

Well officially P & A at 2:00 p.m. on 12-9-76.

**APPROVED** OIL CON. DISTRICT ENGINEER

18. I hereby certify that the foregoing is true and correct Agent TITLE

(This space for Federal or State office use)

APPROVED BY CONDITIONS OF APPROVAL, IF ANY:

DATE