

Conditions of approval, if any:

Recompletion Procedure
Regina #6
B 34-24N-1W
Rio Arriba County, New Mexico

1. MIRU
2. Fill hole with water.
3. Set CIBP @ 2965'; Mix 2 sx cmt, spot a plug from 2965' to 2915'. Fill well with water and pressure test casing to 500#.
4. Perforate 2772 to 2775 at 4 SPF. Make a swab run. If well kicks off, RD.
5. If well does not make gas, set CIBP @ 2750'.
6. Perforate 2610 to 2613' at 4 SPF. Make a swab run.
7. RDMO.