

- 07-24-80 Run 1-1/2" tubing in hole. Clean out with air to 3351', making est. 50 MCF gas with heavy spray of water. Lay down 2 jts and SDON. Leave blowing to atmosphere. (JCA)
- 07-25-80 Run in and tag with 1-1/2" tubing. Wellbore still clean to 3351'. Land with 103 jts. in hole @ 3334'. Unload with air compressor. Making drilling mud, cotton seep hulls, water, etc. Very little gas. Rig down and move off. (JCA)