

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

PERMIT IN TRIPPLICATE
(Other instructions on re-
verse side)

Ex. 104 B. Form No. 1004-1033
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

87 NOV -9 AM 9:32

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2 NAME OF OPERATOR

Chace Oil Company, Inc.

3 ADDRESS OF OPERATOR

313 Washington SE, Albuquerque, NM 87108

4 LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)

At surface

Unit 'C' 660 FNL & 1650' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether BV, HT, OR, etc.)

5 LEASE DESIGNATION AND SERIAL NO

Jicarilla 70

6 IF INDIAN, ALLOTTEE OR TRIBE NAME

Jicarilla Apache

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Jicarilla Apache 70

9. WELL NO.

70-10

10. FIELD AND POOL, OR WILDCAT

South Lindrith Gallup Dakota

11. SEC., T., R., N., OR S.E. AND
SURVEY OR AREA

Sec. 34, T24N, R4W

12. COUNTY OR PARISH

Rio Arriba

13. STATE

New Mexico

16 Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON ☒

CHANGE PLANE ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17 DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)

On October 23, 1987, your office approved the attached plugging procedure.

After reviewing the procedure, I realized that there is a more effective way to plug
this well. It would be appreciated if you would consider the revised plugging
procedure.

- 1) Rig up, nipple up BOP. Lay down 2 3/8" tubing while coming out of hole.
- 2) Hook up cement pump truck to 4 1/2", 10.5# casing.
- 3) Pump a total of 177 sks (299 cf) of 13.0 lb./gal. Class 'B' cement.
152 sks (256.88 cf) to fill 4 1/2" casing to surface.
25 sks (42.25 cf) pumped into formation.
- 4) Shut well in for 24 hours.
- 5) Remove casing head.
- 6) Set dry hole marker.
- 7) Fill all pits, disk and reseed location.
Bar ditch, access road, reseed.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Vice President Production

DATE

11/06/87

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side