

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>	
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Santa	
9. Well No. 1	
10. Field and Pool, or Wildcat Undes. Nacimiento	
12. County Rio Arriba	

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER- <u>Dry Hole</u>
Name of Operator Jerome P. McHugh		
Address of Operator P O Box 208, Farmington, NM 87499		
Location of Well UNIT LETTER <u>N</u> <u>790</u> FEET FROM THE <u>South</u> LINE AND <u>1850</u> FEET FROM <u>West</u> <u>2</u> TOWNSHIP <u>24N</u> RANGE <u>2W</u> NMPM.		

15. Elevation (Show whether DF, RT, GR, etc.)

7224' GL; RKB = GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
WELL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugged and abandoned well 12-31-81; surface restoration in spring of 1982.

1. Spotted 200' bottom plug from 2262-2462' using 30 sx cement.
2. Spotted 100' plug from 1500-1600' using 15 sx cement.
3. Spotted 100' plug from 50-150' using 15 sx cement.
4. Installed dry hole marker with surface plug of 5 sx of cement.
5. Filled and leveled all pits.
6. Location cleared and cleaned of all junk.
7. Cut dead man wires.

Location ready for inspection.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Sherman E. Dugan</u>	TITLE <u>Agent</u>	DATE <u>10-27-82</u>
Original Signed by CHARLES CHOLSON		
APPROVED BY	TITLE <u>DEPUTY OIL & GAS INSPECTOR, DIST. #3</u>	DATE <u>JAN 5 1983</u>
CONDITIONS OF APPROVAL, IF ANY:		